

NaOH

CAUSTIC SODA

IMPORTANT!

Please fill out and return

PPG INDUSTRIES, INC.



DANGER!

Caustic Soda Can Cause Severe Burns to Skin and Eyes

Caustic soda (also called lye or sodium hydroxide) attacks the skin and eyes rapidly. Even a small quantity of a dilute solution can severely injure the eyes or cause blindness. Overexposure to caustic soda by way of skin burns or swallowing can cause death.

Persons working with caustic soda should wear protective clothing and close-fitting goggles at all times.

Caustic soda is a reactive chemical and can react with certain other chemicals and metals to produce explosions.

Read Chapter 3 for more information on the hazards of caustic soda, on protective devices and on first aid.

In case of emergency, call PPG Industries Chemicals Group Emergency Response Center in Natrium, West Virginia, (304) 843-1300. This telephone is manned to answer 24 hours a day.

**CAUSTIC
SODA
LIQUOR**
UN1824

**CAUSTIC
SODA
BEADS**
UN1823



EMERGENCY TELEPHONE NUMBER
PPG INDUSTRIES, INC., NATRIUM, W.V. **(304) 843-1300**

Table of Contents

CHAPTER	PAGE
1. Introduction	2
2. Purchasing Information Caustic Soda Liquor PELS® Caustic Soda Beads	6
3. Protective Devices and First Aid	14
4. Caustic Soda Liquor Handling and Storage Equipment	18
5. Caustic Soda Liquor Unloading and Handling	22
6. PELS Caustic Soda Beads Unloading and Handling	30
7. Technical Data	34
8. Methods of Analysis	54
9. Uses of Caustic Soda	66
10. Methods of Manufacture	68
PPG Chemicals for Industry	74
PPG Chemicals Sales Offices	76

INTRODUCTION

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

PPG Industries Chemicals Group, one of the world's largest producers and suppliers of caustic soda, has four caustic plants strategically located in the United States and Canada. These plants serve a large and highly diversified group of consumers located throughout North America and overseas.

The combination of high-volume caustic soda production plus orientation as a supplier of caustic soda to North America enables PPG to back up its product with a coordinated system of services important to all caustic soda consumers:

- **A network of 10 bulk terminals** for shipment of liquid caustic soda is operated in North America. Over-night service to many customers is made possible by this system of bulk terminals.
- **Versatile shipping capabilities** include tank car, tank truck, barge and ocean-going tanker transportation of caustic soda. PPG owns many hundreds of tank cars designed and used exclusively for caustic soda solution service.

Other PPG rail cars and truck trailers are available for delivery of PELS caustic soda beads. PPG barges serve customers on rivers and inland waterways, while coastal terminals are supplied by ocean-going tanker.

- **Stocks of PELS® caustic soda beads** are maintained at strategically located distribution points throughout the nation.
- **PPG Chemicals Group sales representatives**, thoroughly trained to serve caustic soda customers, operate from sales offices located in major cities throughout the United States, Puerto Rico and Canada.
- **PPG engineers** provide assistance to customers by offering a full range of technical information and consultation. Their services include: recommending systems for unloading, handling and storing various caustic soda forms; assistance in startups and trouble-shooting; advice on form and grade selection.



PPG engineers present safety training seminars.

NaOH

- **Laboratory services** available at several PPG locations include both analytical and applications laboratories.
- **Other activities** encompass technical service engineering assistance in selecting and installing handling equipment and protective devices as well as help with safety training programs. These include providing audio-visual aids such as safety wall charts, booklets and the film, "Take Care with Caustic."

PPG's position as a front-running caustic producer is maintained by an extensive program of research and


development. Its results include many benefits that are passed on to customers. For example, a coating developed by PPG is used as a lining in PPG caustic soda tank cars and barges to protect the high purity of caustic soda received by users. Other technical advances include "CSD," closed system delivery of bulk, dry caustic soda in pressure-differential hopper cars and truck trailers; and PELS caustic soda beads.

PPG's stake in caustic soda is big—and long range. It includes a commitment to meet its customers' needs for material—and service.



Analytical laboratory technicians test production samples of caustic soda.

INTRODUCTION



○ Tank Cars and Tank Trucks

■ Barges

* Ocean-going Tankers

A network of caustic soda distribution points assures quick delivery.

NaOH

SHIPPING POINTS FOR CAUSTIC SODA SOLUTIONS:

Tank Cars and Tank Trucks

California: Richmond
San Pedro
Illinois: Lemont
Louisiana: Lake Charles
Missouri: St. Louis
New Jersey: Bayonne
Paulsboro
West Virginia: Natrium
Canada: Beauharnois, Quebec
Puerto Rico: Guayanilla
(tank trucks
only)

Barges

Louisiana: Lake Charles
New Jersey: Bayonne
Paulsboro
West Virginia: Natrium

Ocean-going Tankers

Louisiana: Lake Charles

Chapter 2

PURCHASING INFORMATION

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).


GRADES AND FORMS

To meet the needs of various industrial processes, the Chemicals Group of PPG Industries produces caustic soda in a wide range of grades and forms. Caustic soda solutions are available in these grades:

- standard
- low iron
- rayon
- mercury cell

The most common commercial form is the solution containing 50 percent actual sodium hydroxide by weight. PPG Industries also produces the more concentrated solution form, approximately 73 percent actual sodium hydroxide by weight.

PPG Industries manufactures anhydrous caustic soda in the modern beaded form bearing the trademark PEELS. The beads come in one optimum size averaging 0.7 millimeter in diameter. Their size uniformity is an advantage for repacking and compounding. Their one optimum size eliminates the need to store numerous grades of anhydrous caustic soda.




Liquid caustic soda available in 50 and 73 percent solutions.

SELECTING THE OPTIMUM GRADE AND FORM

Among the factors in selecting the most economical grade and form of caustic soda for a particular application, besides purchase price, are the costs of: transportation, unloading, handling within plant, preparing caustic soda for use, and the investment in equipment for unloading, storage, handling and preparation.

Representatives of PPG Industries Chemicals Group will gladly cooperate in determining the most economical and best-suited grade and form for any operation.

NaOH



PELS® caustic soda beads show little or no dust.

PURCHASING INFORMATION

CAUSTIC SODA SOLUTIONS

Shipping

Caustic soda solutions are shipped from PPG manufacturing plants as 50 percent solutions and 73 percent solutions by weight. The company's nationwide network of terminals stocks 50 percent solutions in strategic geographic locations for prompt delivery by tank cars, tank trucks and barges to many parts of the United States.


PPG Industries ships 50 percent caustic soda solution in ocean-going tankers to terminals on the east and west coasts for domestic users as well as for export. The company's large fleet of barges carries caustic soda solutions to inland and coastal terminals and customers' docks.

PPG engineers will assist companies in evaluating and designing new unloading facilities for tank cars, tank trucks or barges.

To prevent metallic contamination and maintain the high purity of caustic soda shipments, PPG lines all cargo tanks of tank cars and barges.



Loading caustic soda solution into tank car.



Loading caustic soda solution into ocean-going tanker at PPG plant in Lake Charles, Louisiana



Caustic soda tank car.

Tank Cars

PPG maintains a fleet of many hundreds of tank cars for caustic soda service only. They are designed for safe and efficient unloading of caustic soda solutions. Every PPG tank car is equipped for either top or bottom unloading.

PPG tank cars are well insulated, so that freezing is unlikely except under non-routine conditions such as prolonged transit delays. The cars are equipped with channel-type heaters if heating is required.

Shipments are usually made in tank cars with nominal capacities of 10 and 16 thousand gallons.

Typical Weights of Tank Car Contents

	Nominal Capacity, Gallons	
	10,000	16,000
Liquid basis		
50 percent	128,000 lb	194,000 lb
73 percent	142,000 lb	200,000 lb
Anhydrous basis		
50 percent	33 tons	50 tons
73 percent	52 tons	73 tons

Dimensions of Tank Cars

	10,000-gallon	16,000-gallon
Length	41'2"	43'3 ³ / ₈ "
Height		
Empty	14'7 ³ / ₄ "	14'10 ⁵ / ₈ "
Loaded	14'5 ³ / ₄ "	14'8 ³ / ₈ "
Width	10'7 ¹ / ₂ "	10'0"

PURCHASING INFORMATION

Tank Trucks

Tank trucks provided by common carriers for the shipment of caustic soda solutions must conform to DOT Specification MC310 or MC311. Tank trucks built after May 14, 1967, must comply with DOT Specification MC312. Tanks are generally made of stainless steel. Maximum permissible loads may be limited by regulations of the different states.

The capacities of tank trucks in caustic soda service have not been standardized, but vary between 2,000 to 4,000 gallons. For shipments of 50 percent caustic soda solutions, the corresponding weights would range from 25,000 to 50,000 pounds of liquid. On an anhydrous basis, these shipping weights would range from 6 to 12 tons. The 73 percent caustic soda solution is seldom shipped by tank truck because of its higher freezing temperature of approximately 145°F.

Barges

The barges in the fleet of PPG Industries Chemicals Group are built specifically for transporting caustic soda solutions. These barges are designed to permit maximum safety in unloading. They are equipped with diesel unloading pumps.

Barge capacities range from a minimum of 1,200 liquid tons or approximately 200,000 gallons up to a nominal 3,000 liquid tons or approximately 475,000 gallons. Since almost all barge shipments consist of 50 percent caustic liquor, the actual dry caustic soda content ranges from 600 to 1500 tons.



Caustic soda tank truck at loading platform.



PPG barge dedicated to shipping caustic soda solution.

NaOH

Shipping Points for Caustic Soda Solutions:

See list with map on pages 4 and 5.

Billing Procedure

Caustic soda solutions are billed on a basis that is standard in the United States. However, this basis is rather complicated because of the way it originated. Since the days when alkalis were first manufactured, caustic soda (NaOH) and soda ash (Na₂CO₃) were compared on the basis of their sodium oxide (Na₂O) content. The anhydrous forms of caustic soda in those days were about 98 percent pure. According to the molecular weights of NaOH and Na₂O, 100 pounds of pure NaOH are calculated to contain 77.48 pounds of Na₂O. But the 98 percent purity factor reduces this value to 76 pounds. Today, liquid caustic soda is still sold as "NaOH on a 76 percent Na₂O basis."

Another factor in billing is that the Na₂O content is determined by a laboratory method which includes the Na₂O in both NaOH and Na₂CO₃. The latter is present as a fractional percentage.

For example, assume that a shipment of nominal 50 percent caustic soda solution contains the following percentages by weight of NaOH and Na₂CO₃:

$$\% \text{ Actual NaOH} = 50.00\%$$

$$\% \text{ Actual Na}_2\text{CO}_3 = 0.16\%$$

Based on their relative molecular weights, NaOH contains 77.48% Na₂O while Na₂CO₃ contains 58.48%.

Therefore, the % Na₂O content of the NaOH and Na₂CO₃ in the shipment is as follows:

$$\begin{aligned} \% \text{ Na}_2\text{O in NaOH} \\ = 50.00\% \times 0.7748 = 38.74\% \end{aligned}$$

$$\begin{aligned} \% \text{ Na}_2\text{O in Na}_2\text{CO}_3 \\ = 0.16\% \times 0.5848 = 0.09\% \end{aligned}$$

Therefore, the total % Na₂O is:

$$38.74\% + 0.09\% = 38.83\% \text{ Na}_2\text{O}$$

The billing analysis (% NaOH on a 76% Na₂O basis) is calculated as follows:

$$\begin{aligned} & \frac{\text{Total \% Na}_2\text{O} \times 100\%}{76\%} \\ \text{or, } & \frac{38.83 \times 100}{76} \\ & = 51.09\% \text{ NaOH} \\ & \quad (76\% \text{ Na}_2\text{O basis}) \end{aligned}$$

The pounds of NaOH (76% Na₂O basis) used for invoicing are calculated as follows:

$$\begin{aligned} & \text{Pounds Caustic Soda Solution} \\ & \times \frac{\% \text{ NaOH (76\% Na}_2\text{O basis)}}{100} \\ & = \text{Pounds NaOH (76\% Na}_2\text{O basis)} \end{aligned}$$

PURCHASING INFORMATION

PELS CAUSTIC SODA BEADS

PPG Industries Chemicals Group supplies anhydrous caustic soda in the beaded form bearing the trademark PELS. Drums and bags are designed to be moisture-resistant because anhydrous caustic soda readily absorbs moisture from atmospheric air.

Bulk Shipments

PELS caustic soda beads are shipped in rail cars and truck trailers. The recommended method of handling is the "CSD" closed system delivery method developed by PPG Industries. It utilizes a closed-loop, pneumatic system for pressure conveying.

PPG maintains its own fleet of pressure differential trailers that can make shipments up to approximately 22 tons. These trailers carry equipment for drying the pneumatic conveying air so that the receiving system does not need to have dryers.

PPG Industries Chemicals Group owns the pressure differential rail cars used for CSD shipments. The rail cars are lined with Polyclutch* epoxy resin lining. These cars have a capacity of 3000 to 4000 cubic feet, sufficient for shipments up to 100 tons.

More detailed information on "CSD" closed system delivery appears on page 31 in the chapter on PELS Caustic Soda Beads Unloading and Handling.



The entire pallet load, 1 1/4 tons, consisting of fifty 50-pound bags, is protected by a shrink-wrapped polyethylene film. Pallets holding one-ton loads of forty 50-pound bags are also available.

*A product of PPG's Coatings and Resins Group.

FIRST AID

All persons who handle caustic soda should be familiar with proper first aid procedures.

Fast action is imperative because caustic soda attacks the skin and eye tissues rapidly. Delay greatly increases the severity of a caustic burn; prompt and thorough treatment can reduce the danger of serious permanent damage. **Get the injured person to an eye wash or spray shower immediately! Every second is critical. Be sure that medical attention is obtained as soon as possible if caustic soda has contacted an eye, also if skin contact has resulted in burns, reddening or excessive irritation.**

Eyes

Eyes are particularly sensitive to caustic soda. Even tiny particles of caustic soda dust, or a small quantity of dilute solution, can injure the eye or result in loss of vision.

If caustic soda gets in the eye, flushing the eye immediately with large quantities of water will do more good than the best of medical services can provide later on.

Continue washing for at least 15 minutes. Call a physician.

To make sure that water contacts all surface tissues of the eye and lid, hold the eyelids apart while flushing. The best way to irrigate the under surfaces of the upper eyelid is to raise the eyelid and roll it back. Prolonged irrigation with plenty of water—and only water—is the proper treatment for eyes. **Neutralizing solutions must not be used in eyes.** Chemical neutralization generates heat and may introduce another burn hazard. Diluting caustic soda also generates heat; so use plenty of water to conduct the heat away.


Call a physician, preferably an eye specialist, as soon as possible. Continue eye irrigation until the physician arrives.

Eye-Washing Fountains and Spray Showers

Spray showers and eye-washing fountains or a bubbler fountain should be located in the immediate working area where they can be reached **in seconds.**

Out-of-doors, a hose that is not under high pressure can serve temporarily in place of a shower or eye-washing fountain.

Prominent markings to make the location of safety showers and fountains distinctly visible by means of a sign or conspicuous background color are necessary. Showers and fountains should be tested daily and kept clean and in perfect working order at all times.



Eye-washing fountain and flood shower.

PROTECTIVE DEVICES AND FIRST AID



Proper protective clothing reduces chances of injury.

Protective Clothing

All persons working around caustic soda must wear protective clothing as well as **close-fitting safety goggles**. Do not wear contact lenses when working around caustic soda. Face shields may be worn in addition to—but not instead of—goggles. Gloves, boots, aprons, and other clothing made of rubber or rubber-covered cloth give good protection because rubber is resistant to caustic soda.

Clothing made of polyvinyl chloride also gives good protection. Under the protective clothing, wear cotton clothing rather than woolens, because animal fibers such as wool are rapidly destroyed by caustic, whereas cotton is more resistant. Leather, like wool an animal tissue, is also attacked by caustic. Wear shoes, boots or overshoes made of rubber. Also, wear a plastic safety hard hat with a wide brim all around the head. Set front of hat to slope down over eyes to provide more cover for the eyes. When boots are worn, trouser legs should be on the outside to reduce the possibility that caustic soda might enter the top opening. Wear a long-sleeved shirt and button the collar. Shirt or coveralls should fit snug at neck and wrists.

Respirator

Persons working where caustic soda dust or mist is present should wear NIOSH/MSHA-approved dust-type respirators. Inhalation of dust or mist will irritate the respiratory tract. The OSHA time-weighted average (TWA) for caustic soda is 2 milligrams per cubic meter of air. Work areas where caustic soda dust or mist is present should be well ventilated.

NaOH

Skin

Flush skin immediately and continuously with plenty of water for at least 15 minutes—longer if a soapy feeling persists, which indicates that some caustic soda is still present. **Do not sponge or rub or use small amounts of water.** Large quantities of water are necessary to carry away the heat generated by diluting caustic soda. Do not touch your eyes with your hands or fingers—they might be contaminated with caustic soda.

Caustic soda burns can be most deceiving. A grave danger lies in stopping the flushing with water too soon. What may first appear to be a superficial skin irritation can become a serious burn that may take a long time to heal. The greater the amount and concentration of the caustic soda and its temperature, the more imperative it is to get to a source of water immediately.

Under the safety shower, remove clothing that has been in contact with caustic. Continue flushing while removing clothing. Do not remove safety goggles unless caustic soda has been washed off completely under the shower. Persons helping a man with caustic soda on his body or clothing should wear safety goggles to make sure that their own eyes don't get splashed with water contaminated by caustic soda.

A less serious condition, stinging due to caustic soda mist or dust on exposed skin, can be stopped by rinsing with a ten-percent solution of ammonium chloride. Diluted vinegar may also be used to stop stinging. Do not use neutralizing solutions in the eye.


Swallowing

If a person swallows caustic soda, give plenty of water to drink. Afterwards, citrus juices or weak vinegar solutions may also be given. **Do not induce vomiting** because passing the caustic soda through the food pipe, throat and mouth a second time will result in more damage to these tissues. Caustic soda causes

severe damage to mucous membranes. If a person has swallowed caustic soda, call a physician at once. **Don't give anything by mouth to an unconscious person.**

Shock

If a patient suffers from shock, place him on his back and keep him warm until a doctor arrives.



Plant ambulance equipped with portable eye wash fountain.

Chapter 4

CAUSTIC SODA LIQUOR HANDLING AND STORAGE EQUIPMENT

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

MATERIALS OF CONSTRUCTION

Iron and steel are the usual materials of construction for equipment handling 50 percent solutions of caustic soda below 140°F. Nickel, nickel alloys and stainless steel are required at higher temperatures, for higher concentrations, or for operations where iron pickup of a few parts per million cannot be tolerated.

To prevent metallic contamination in transit, PPG Industries uses a latex lining on the interior of tank cars and barge tanks. Tank trucks are ordinarily constructed of stainless steel but their interiors may also be lined.


Designers of equipment for handling and storing caustic soda may want to evaluate other materials and new products. PPG engineers will gladly advise on the selection of construction materials for individual applications.

Stress-Corrosion Failure

Commonly called "caustic embrittlement," stress-corrosion failure occurs at areas of mechanical stress or where fabricating operations produce high residual stress such as at bends in piping and at welds.

As shown in the graph, mild steel is subject to stress-corrosion failure under conditions that depend upon temperature and also upon concentration. These conditions would exist in the area above the curve in the graph. To prevent stress-corrosion failure, temperatures of 50 percent caustic soda solutions should **not** be permitted to go above 140°F.

Stress-Corrosion Cracking of Mild Steel



Generally accepted practices suggest temperatures to 140°F.

(National Association of Corrosion Engineers Technical Practices Committee Report, Publication 51-3)

Corrosion Rates in 50% NaOH

Metal	Corrosion Rate, Mpy		
	At 100°F ^a	At 135°F ^b	At 131 to 167°F ^c
Titanium	<0.1	0.5
Zirconium	<0.1	<0.1
Nickel	<0.1	<0.1	<0.1
Monel ^d alloy 400	<0.1	<0.1	<0.1
Inconel ^d alloy 600	<0.1	<0.1	<0.1
Ampco ^e 8	1
Mild steel	0.7	5	8
Copper-nickel (70-30)	<0.1
18-8 stainless steel	0.1
Ni-Resist ^f Type 1	2
Cast iron	10.5

^aDuration of test: 162 days. ^bDuration of test: 135 days. ^cDuration of test: 30 days

^dTrademark of The International Nickel Co., Inc. ^eTrademark of Ampco Metal, Inc.

^fTrademark of Thomas Foundries, Inc.

MATERIALS ATTACKED BY CAUSTIC SODA

Certain metals, such as aluminum, magnesium, zinc, tin, chromium, brass, and bronzes made with zinc or tin are attacked by caustic soda. They should be avoided as parts of equipment; for example, brass bearings. Also items such as safety hats, buckets, drums and ladders made of aluminum should not be used with caustic soda.


Since galvanizing is done with zinc—which is attacked by caustic soda—keep the liquor away from galvanized iron surfaces. The reaction of caustic soda with zinc is vigorous and—under some conditions—may be dangerous because hydrogen is generated and may introduce an explosion hazard.

Silica-containing materials such as glass, brick and tile are attacked by caustic liquor. The action is slow and will at first only contaminate the caustic with silica, but failure of the material will eventually follow.

Copper can seriously contaminate caustic soda even though it may not be severely attacked. Caustic handling equipment made with copper or copper alloys can be harmful to certain manufacturing processes, such as the production of hypochlorite bleaches, because of their great sensitivity to copper contamination.

PIPE LINES

Wrought iron or mild steel is suitable for pipe lines and fittings to convey caustic soda solutions below 140°F; nickel is customary for hotter solutions. Monel alloy or stainless steel may be used under certain conditions. Polypropylene-lined steel pipe has been used with solutions up to 225°F. Outdoor pipes should be insulated and, if air temperatures fall below 65°F, electrically-traced.



Plastic flange cover.

Welded or flanged joints are preferable to screwed fittings.

Many different types of plastics and elastomers may be used with caustic liquor but the upper temperature limit, of course, is different for each plastic. Gaskets should be made of a good grade of rubber. **Materials whose capabilities for caustic service have not been established by experience should be adequately tested in advance.**

Pipe lines should slope so as to be self-draining. Caustic liquor left in pipe lines has a passivating effect and retards corrosion; however, it should not be left in pipe lines if temperatures may reach the freezing point of the solution. Water should be available for washing out sections of line where there is danger that caustic liquor might drip and contact personnel.

New piping installations should **always** be tested with water for leaks

before caustic liquor is run in. Plastic covers on flanged joints, also guards over pump packing glands, prevent spraying of caustic liquor if leaks develop.

Process piping under 1-inch diameter is not recommended. Larger sizes permit greater flow-through and minimize the possibility of plugging or freezing.

Unloading Lines

Tank car unloading lines are usually 2-inch diameter pipe because this is the standard fitting size on caustic soda tank cars.

Flexible hoses are preferred for connecting a tank car to the unloading pipe line because the car rises during unloading. Spiral-wire-wound hoses made of alkali-resistant material are suitable. These hoses should have clamped "combination nipple" ends made of cadmium-plated malleable iron. Hoses may also be made of stainless steel.

CAUSTIC SODA LIQUOR HANDLING AND STORAGE EQUIPMENT

PUMPS

For transferring caustic liquor from tank car to storage or from storage to point of use, centrifugal pumps are recommended. All-iron construction is generally suitable, although nickel and nickel-cast-iron pumps give longer service life. Above 140°F, a nickel or nickel alloy pump must be used. Brass fittings and bearings should be avoided, especially at high temperatures or concentrations of 50% or above. To prevent leakage at the pump shaft, deep stuffing glands with high-grade graphite-asbestos packing are preferred to mechanical seals for intermittent service. Mechanical seals are suitable for continuous service.

VALVES

Iron or steel plug valves of the lubricated type give good service for normal use. For high-temperature use, nickel-cast-iron plug valves or nickel gate valves with deep packing glands should be used. Stainless steel can also be used in some cases.

Other types of valves commonly used include non-lubricated ball valves and gate valves made entirely of iron or steel.

Brass valves should be avoided, especially at high temperatures or concentrations of 50% or above, because they are corroded by caustic soda and will leak. They can also introduce copper contamination that

can be harmful to certain manufacturing processes.

METERS

There are several types and designs of highly accurate meters with excellent reproducibility that are made of materials resistant to caustic soda solutions. **Meters with brass parts, such as used in water meters, would be corroded by caustic soda.** Suitable meters are available with attachments to compensate for changes of specific gravity with temperature where this degree of accuracy is required.

The selection includes automatic and semi-automatic meters for continuous or batch operations. They range in capacity from 0.1 gallon per minute to hundreds of gallons per minute.

PPG engineers will be glad to advise on the type and size of meter required for any installation.

STORAGE TANKS

The most popular construction material for storage tanks holding caustic soda solutions is mild steel because of its lower cost and satisfactory performance under most conditions.

The 50 percent solution should be stored at 75 to 100°F. Below 75°F, viscosity increases rapidly and pumping becomes difficult. Above 140°F, iron pickup increases and stress-

corrosion cracking may become a problem.



Preventing Caustic Attack and Iron Pickup

Even localized high temperature can accelerate caustic attack. For example, heating coils carrying steam will have a surface temperature of at least 212°F. Coils made of nickel or nickel alloys such as Monel and Inconel are highly resistant to attack even at temperatures far above 290°F, the boiling point of a 50 percent solution of caustic soda. Coils located too near the side of the tank are known to have caused stress-cracking as well as accelerated corrosion of the tank walls. Piping and storage systems should be checked throughout to make sure that local overheating will not occur.

Both metallic contamination and stress-corrosion can be eliminated by a special coating applied to the inside of the tank. Columbia No. 7 Neoprene lining, which is available from PPG's Coatings and Resins Group, has given excellent results. It should be applied by licensed applicators only.

Areas of unrelieved high stress, such as welds, are susceptible to caustic attack. Many tanks can be completely stress-relieved by the fabricator; the cost may be considered as insurance against failure. Many welds made in the field have been locally stress-relieved with satisfactory results.

Typical Storage Tanks for 50-Percent Caustic Soda Solutions



Preventing Freezing

The storage temperature of 50 percent caustic soda solutions should not go below 75°F. At lower ambient temperatures, tanks should be insulated. If these solutions are stored out-of-doors in cold climates, the tanks should be insulated and heated. Steam coils made of nickel submerged in the solutions are the usual method of heating.

If storage capacity is available, dilution is an effective way to avoid freezing problems. For example, a 20 percent solution freezes at approximately -17°F.

Tank Capacity and Strength

Storage capacity should exceed the volume of the largest shipment planned by at least 50 percent. A stronger tank is needed than for water because the weight of a 50 percent caustic soda solution is around 1½ times the weight of water or approximately 12¾ pounds per gallon.

Curbings and Spills

As a safety measure in case of spills, curbings should be erected around a tank. These structures permit recovery of spilled caustic liquor in some cases; in others, they reduce the hazard of disposing of spills. When most of a spill has been removed, the rest should be cleaned up with lots of water. Final traces of caustic soda can be neutralized with dilute acid or sodium bicarbonate solutions.

Do not dump caustic soda solution into streams or waterways.

Chapter 5

CAUSTIC SODA LIQUOR UNLOADING AND HANDLING

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

This chapter describes the unloading of tank cars and the dilution of 73 percent caustic soda solutions.

When requested, PPG engineers will assist companies in evaluating and designing new unloading and handling systems for bulk caustic soda in solution forms.

CAUSTIC SODA SOLUTIONS

Although the procedures described in this section refer to unloading tank cars, the principles apply in general to tank trucks and barges. PPG engineers will gladly advise on procedures for unloading and handling, since no two installations are alike.

Procedures for unloading 50 or 73 percent caustic soda solutions are the same up to the point where the flexible connection from the tank car ends. From there on they differ because the 73 percent solution is usually diluted before storage.

PREPARING TANK CARS FOR UNLOADING

The suggestions that follow are based on procedures developed over the years. While certain steps appear obvious, the procedure would not be complete without them. A detailed listing of steps is helpful from the safety standpoint too, because apparently obvious precautions are sometimes neglected.

Placing Car for Unloading

1. After the car is properly spotted, set handbrake and block wheels.
2. The U.S. Department of Transportation regulation states that caution signs must be so placed on the track or car as to give necessary warning to persons approaching car from open

end or ends of siding and must be left up until after car is unloaded and disconnected from discharge connection. Signs must be of metal or other suitable material, at least 12 by 15 inches in size and bear the words "STOP—TANK CAR CONNECTED," the word "STOP" being in letters at least 4 inches high and the other words in letters at least 2 inches high. The letters must be white on a blue background.

3. Derails should be placed at the open end or ends of the siding approximately one car length from the car being unloaded.

SPECIAL PRECAUTIONS


Storage tank inspection: Before connecting the tank car to the unloading line, make sure the storage tank is vented and the vent is open. Air displaced by the caustic soda solution must be permitted to escape, otherwise the pressure could rupture a tank. **Also make sure there is room for the contents of the car so that no caustic soda solution will overflow the tank.**

Lighting: During the hours of darkness no attempt should be made to connect or disconnect a car or to open or close any attachment unless adequate lighting is provided.


Do not enter cars under any circumstances because of the possibility of caustic burns or suffocation due to insufficient oxygen.

Moving partially unloaded car: The movement of partially unloaded cars should be avoided. However, if it should be absolutely necessary to move a partially unloaded tank car, make sure the outlet valve is closed and all connections to the car have been disconnected. The manway cover should be closed and all bolt closures tightened securely. Unloading lines should be drained.

Safety check: To prevent caustic soda from contacting personnel, make sure that all unloading connections, piping, joints, valves and storage tanks are sound and tight before unloading. After flow starts, check all around again for leaks.




Wheel check for tank cars.



Derailed. Stop sign stands between tracks.

Preheating Liquid in Tank Car



Sampling

Since a sample is taken at the time of loading, many users accept the shipper's analysis. However, PPG Technical Service engineers will be glad to recommend a procedure for sampling tank car shipments.

Preheating Liquid in Tank Car

All PPG tank cars are insulated so that caustic soda liquor is unlikely to freeze—but it may if the tank car delivery is delayed. The 50% caustic soda solution is entirely fluid and can easily be unloaded when its temperature is above 80°F.

The same goes for the 73% solution when its temperature is above 185°F. Difficulty may be encountered in attempting to unload at lower temperatures since viscosity is then greater and there is a hazard of freezing in the unloading lines. Crystals start to form well above the freezing point.

Also, caustic soda solution near the top

of a tank car may be as much as 20 degrees hotter than liquor near the bottom. In fact, the bottom layer may have solidified even though the temperature at the top is well above the solution's freezing point.

If a crust has formed on top of the caustic soda solution, break it up before heating the car contents so the solution can expand without exerting dangerous pressure on the crust. You can break it by inserting a U-tube through the manway onto the crust and applying steam through the U-tube. **Never apply live steam directly onto the surface of caustic soda because of the danger of eruption.**

To apply steam to preheat the tank car contents before unloading, attach a steam line to one of the connections. Install a steam trap on the other connection (see diagram).

The steam connections shown in diagram on both sides of the discharge

leg are for cars with heating channels. **In extremely cold weather**, heating channels should be drained and blown out with compressed air to prevent freezing and left open to permit any condensate still remaining after air-blowing to drain out.

Wet or saturated steam (**not superheated**) below 50 pounds per square inch and 300°F must be used because **steam at higher temperatures will damage the car lining** and may result in contamination of the caustic liquor. Apply steam gradually to prevent mechanical stresses. Heat should never be applied to a car by blowing steam into the caustic liquor.

Disconnect all steam lines as soon as the proper unloading temperature has been obtained. No heat should be applied during the actual unloading because the car lining will be damaged.

CAUSTIC SODA LIQUOR UNLOADING AND HANDLING

Thawing Frozen Bottom Discharge Cock and Internal Valve at the Bottom of a Car

The bottom discharge cock can be freed by steaming internally through the valve opening or externally on the surface of the cock.

If the internal valve cannot be opened with reasonable pressure on the valve handle, it indicates that caustic soda around the valve is frozen and heat should be applied to free it. **Do not attempt to force the valve by applying extreme pressure to the valve handle as this may break the pin connecting the valve to the valve rod and make bottom unloading impossible.**

The internal valve can be freed by inserting a steam lance of 1/4" copper tubing up through the bottom discharge cock and playing live steam directly onto the internal valve. After a period of 10 to 15 minutes, the frozen caustic soda will

have melted. The internal valve can now be opened.

Be sure to withdraw lance and close bottom discharge cock before again trying to open internal valve.

Preheating Unloading Lines


In cold weather it is good practice to preheat unloading lines to prevent cooling and solidifying of caustic soda solutions at the start of unloading. Preheating may be done by passing steam directly through the

line. Sections of the unloading line exposed to temperatures below 60°F should be insulated.


An alternative method of preheating a line for unloading 73% caustic soda solution is to fill it with water immediately before unloading. When the concentrated caustic soda solution contacts the water, heat will be generated and will prevent the solution from being frozen by the cold pipeline.



Steam lance helps loosen frozen valves.




Testing internal valve handle.




Steam line should always be removed prior to unloading car.

NaOH

Unloading Through Bottom Outlet Valve



Unloading Through Eduction Pipe By Air Pressure



CAUSTIC SODA LIQUOR UNLOADING AND HANDLING

METHODS OF UNLOADING

Two methods are preferred for unloading tank cars:

1. Through the bottom outlet valve with a pump.
2. Through the top by way of the eduction pipe with air pressure.

Unloading Through Bottom Outlet Valve


1. Check the inside valve handle on top of the car and make sure it is closed. If it is not, then the internal valve is not completely closed. Vibration in transit can loosen the internal valve and permit caustic liquor to leak by and become trapped above the bottom cock.
2. Carefully open the one-inch cock on the air connection at the top of the car to release any pressure or vacuum that might be in the car. Cup palm of rubber-gloved hand over top of one-inch cock to prevent caustic soda from spraying on you.
3. Open the manway cover and support it in a partially open position during unloading. Underneath the manway cover handle are two eyebolts which have the nuts mounted in such a way that they cannot be removed and the eyebolts cannot be swung out of the way until the cover has been lifted slightly. This is a safety device to keep the cover from being blown open.
4. On the manway cover nut-and-bolt fastenings, use only end wrenches—not pipe wrenches.
5. Make sure the bottom cock is closed, then, while cupping palm of rubber-gloved hand over the bottom cock to prevent caustic soda from spraying on you, remove the plug. Caustic liquor that might have leaked through the internal valve and become caught between the internal valve and bottom cock could come out

as a spray if the bottom cock is not closed before the plug is removed.


6. Connect unloading line to the 2-inch bottom cock.
7. See that **all** valves on the unloading line are in the proper position for unloading.
8. Open the bottom cock.
9. Open internal valve. If this cannot be done with reasonable pressure, see earlier section entitled "Thawing Frozen Bottom Discharge Cock and Internal Valve..." page 24.

10. Start pump.


11. After flow starts, check piping valves and hose for leaks.
12. Check unloading progress from time to time by looking into the manway.
13. When the car is empty, stop the pump and close the internal valve. Inspect the car through the manway to make sure it is empty.
14. Prepare empty car for return (see final section of this chapter for instructions).



Tank car fittings at bottom of car.



Fittings and hatch cover, domeless car.



Tank car fittings at top of car.

Top Unloading Through Eduction Pipe by Air Pressure

1. Make sure the manway cover is securely fastened in place and all nuts on the cover are tightened.

2. Inspect all fittings at top of car for defects before unloading to avoid possible injury from caustic spray after the car is put under air pressure.

3. Every PPG car has a safety rupture disc set at 100 pounds per square inch. The air pressure should never exceed 75 pounds per square inch (maximum). Higher pressures may fracture the rupture disc in the safety vent. If a disc is ruptured while unloading, call the nearest office of PPG Industries Chemicals Group for further instructions.

4. The air supply line should be equipped with a pressure relief valve set at 75 pounds per square inch (maximum); a pressure-reducing valve set at 70 pounds per square inch (maximum); a pressure gage; and a shut-off valve.

5. Remove the plug from the 1-inch air valve on top of the car. Open the 1-inch cock to relieve air pressure or vacuum. Cup palm of rubber-gloved hand over cock to prevent being sprayed.

6. Check to see that the 2-inch cock on top of the car is closed. Remove the 2-inch plug and connect the eduction pipe to the unloading line with a flexible hose. Open the cock.

Use of a flexible hose for connecting tank car to unloading line is recommended. This will facilitate making connections and prevent a possible rupture of the line because the car rises during unloading as the weight on its springs decreases. This rise may be as much as 6 inches.

Continued on next page

CAUSTIC SODA LIQUOR UNLOADING AND HANDLING

7. Connect the air supply line to the 1-inch cock. This connection, which should also have flexibility, can be made by using pressure hose or flexible tubing.

8. Apply air pressure slowly until there is a normal flow of caustic liquor to the storage tank. Use of minimum air pressure is recommended.

9. If, after applying air pressure, no caustic flows out of the car, contact PPG Industries Customer Service Group.

10. Check fittings and line for leaks.

11. Maintain the air pressure until the tank car is completely empty. A

drop in the pressure and the sound of air rushing through the discharge pipe tell you that the tank car is empty.

12. Shut off the air supply and 1-inch cock on the car. Disconnect the air supply piping. Cupping your rubber-gloved hand for protection, open the 1-inch cock on the car to make sure pressure has been released from the car before opening the manway cover. Then open the manway cover and inspect the car to make sure it is empty.


13. Prepare empty car for return (see section on page 29 for instructions).

Unloading and Diluting 73 Percent Caustic Liquor

Since 73 percent caustic soda solution has a freezing point of approximately 145°F, it is shipped in lined, insulated tank cars at temperatures calculated to arrive at 175 to 200°F. The hot concentrated solution is usually diluted to 50 percent and cooled before storage to reduce handling problems, embrittlement of storage tanks, and iron contamination from tanks.

PPG Industries Chemicals Group developed a system that has been used since 1939 for unloading and

System for Unloading and Diluting 73 Percent Caustic Soda Solutions



diluting 73 percent solution. Many years of service in numerous installations have shown the system to be practical and economical. It needs little supervision.

As shown in the schematic diagram, the system discharges 73 percent solution from the tank car to a centrifugal pump. Dilution water at constant pressure is also fed to the suction side of the pump. A rotameter indicates the flow rate of dilution water. A valve controls the amount of water needed to give the 50 percent strength or any other desired concentration.

Heat evolved by the diluting reaction can raise the temperature of the diluted 50 percent solution to as high

as 270°F. For safe storage in a steel tank, solution temperature should be less than 140°F. To cool the caustic liquor, it is pumped through a heat exchanger before going to storage. The liquor concentration can be determined by simple measurements of specific gravity and temperature, and can be used to control dilution.

PPG engineers will gladly assist in planning and installing the dilution system.

Preparing Empty Cars for Return

1. Clean out unloading lines with steam, water or air before disconnecting. When disconnecting and draining the unloading line, be careful not to spill caustic soda solution

on personnel, the tank car or the ground. Wash off with water any accidental spill on the car to minimize damage to car and to protect trainmen who will be handling the empty car.

2. If steam line and steam trap were used, remove them from car. **In extremely cold weather**, blow out car's heating coils or channels with compressed air.

3. Close all valves. Replace the bottom outlet plug, or the eduction pipe and air inlet plugs. Close and tighten the manway cover and valve housing cover at top of car.

4. Reverse the DOT "CORROSIVE" placards to show the car is empty, but contains a residue.

Unloading Tank Trucks

Tank trucks are almost always unloaded by the driver. Trailers are equipped with 30 feet of hose unless additional hose is specified on the order. The hose is fitted with a two-inch quick-connect coupling. The receiving installation should have a two-inch quick-connect fitting on the pipe to storage. This pipe should be marked with a caustic soda warning sign.

The trailer can be unloaded by air pressure from a blower mounted on the truck. If a pump is needed on the truck for unloading, this should be specified on the order.

The unloading area must have a safety spray shower and eye-washing fountain for the driver's protection.



Hoses, valve and unloading connection at rear of tank truck.

Chapter 6

PELS® CAUSTIC SODA BEADS UNLOADING AND HANDLING


Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

BAGS AND DRUMS

Apart from taking care to avoid breaking or puncturing bags and drums of PELS caustic soda beads, users may handle these containers like those for inert materials. Since anhydrous caustic soda left exposed to the atmosphere absorbs moisture and reacts with carbon dioxide, containers must be kept closed. The contents of broken bags or drums must be promptly used or placed in suitable air-tight containers. Drums and bags should be stored in a dry place indoors.

Dissolving PELS beads: A short period of mechanical agitation is all that is needed to dissolve this form of caustic soda in water completely. PELS beads dissolve twice as fast as flakes.

CAUTION: Do **not** add water to caustic soda beads. The right way is to add the beads slowly to the surface of cold water that is being stirred. If the water is not stirred, adding caustic soda beads is dangerous and can result in spattering and eruption. Don't raise the concentration of caustic soda by more than 5% with any single addition. Do not add caustic soda beads to hot water. The water should be at ambient temperature. The high heat of solution of dry caustic soda may cause sudden evolution of steam and spattering. Also a layer of concentrated solution may form and suddenly mix with a layer of less concentrated solution. In this case, the high heat of dilution may create steam and cause the solution to spatter.



Pressure differential rail car for delivery of PELS® caustic soda beads in bulk.

Disposing of Drums

Flush all traces of PELS caustic soda beads from drums. And then flush again to get rid of any dissolved caustic soda adhering to the metal before disposing of drums. This will protect people handling these drums later on who may not recognize the traces as being caustic soda or be aware of its dangers.

Cleaning up Spills and Disposing of Waste

When cleaning up a spill, wear proper protective clothing and equipment. Shovel up any spilled PELS caustic soda beads. Do not put unneutralized waste caustic soda into a sewer or stream. Follow an approved procedure for neutralizing the spilled material and getting rid of it in your waste disposal system.

Flush the area contaminated by the spill with huge quantities of water.

NaOH

CSD (CLOSED SYSTEM DELIVERY) BULK UNLOADING AND HANDLING

PPG Industries Chemicals Group engineers designed "CSD," a closed system delivery method for bulk shipping, handling and storing PELS caustic soda.

The company has a number of pressure differential rail cars designed for pneumatic unloading. Each has a Polyclutch® epoxy resin lining. PPG also maintains its own fleet of lined pressure differential truck trailers.

Advantages of CSD Rail Car System


1. HIGH SPEED: Unloading rate ranges from 15 to 20 tons per hour. A 90-ton car can be unloaded in less than an 8-hour shift.

2. REDUCED MANPOWER: One man can carry out the entire unloading procedure. There is no need to unload drums from boxcar or truck; move them to storage area; and stack them.


3. INCREASED SAFETY: Closed loop pneumatic conveying system helps protect personnel against contact with caustic soda.

4. IMPROVED HANDLING: When exposed to the atmosphere, caustic soda readily absorbs moisture. The crystals become soft and tacky so that crusts and lumps can form in storage. By exposing caustic soda only to dry air in a closed loop system, CSD avoids caking and retains the original free-flowing characteristics of anhydrous caustic soda.

5. ALL-WEATHER OPERATION: Rain and temperature extremes do not interfere with enclosed pneumatic conveying system; do not stop unloading operations.



Manifold piping of pressure differential rail car.



Automatic loading of pressure differential rail car.

PELS® CAUSTIC SODA BEADS UNLOADING AND HANDLING

CSD operation

The diagram below shows the main components of a typical CSD closed loop pneumatic system.


When conveying air is admitted to the system, it passes over a desiccant to dry the air to a minimum dew point temperature of -40° (measured at atmospheric pressure). The blower compresses the air at a rate of 600 cubic feet per minute to 15 psig. Upon leaving the blower, the air is cooled in a heat exchanger to a temperature less than 140°F . The air then enters a manifold on the underside of the car through piping and flexible hose. The air is distributed from the manifold to the car interior and to the conveying

line. When sufficient pressure has built up in the car, a discharge valve is opened. Anhydrous caustic soda can now flow into the conveying line. The caustic soda is carried through the conveying line by a high velocity air stream to the top of the storage bin.

After the conveying air leaves the storage bin, any entrained dust is removed by an automatic self-cleaning bag-type filter. The filtered air is returned to the blower intake to complete the pneumatic loop. Since the recycled air has been in contact with highly hygroscopic caustic soda, this air is extremely dry. Any make-up air that is required enters the closed loop through the air dryers at the

blower section. The air dryers reduce the dew point of the make-up air to -40°F .

Between unloading operations, the storage bin and other parts of the system are protected against moisture pickup by the same dryers that admit air to the system. The economical design plus the dual purpose of the dryers is a unique feature of CSD.



CSD bulk unloading system for rail cars.

NaOH



Pressure differential hopper trailer for delivery of PELS® caustic soda beads in bulk.

Advantages of CSD Truck Trailer System


Trucks with hopper trailers deliver 20-ton shipments. These systems have the same advantages just described for rail car systems plus additional benefits.

A blower is mounted on the truck and a dryer is mounted on the trailer (see photo and diagram) so that the receiving installation needs to include only a dust filter, a storage bin fitted with a vent dryer and piping from the truck to the storage bin. Accordingly, the investment for a system to receive truck trailer shipments is less than one designed for rail car deliveries.


CSD System Design

Since anhydrous caustic soda is less corrosive than solutions, its demands upon materials of construction are less critical. Steel is the usual material. A smooth, continuous surface inside the conveying line and a minimum of bends promote the efficiency of pneumatic conveying.

Each installation requires an individual design dependent upon existing plant facilities. Engineers of PPG Industries Chemicals Group will assist in evaluating, planning and designing the complete system.



CSD bulk unloading system for truck trailers.



Dryer for closed system delivery is mounted on trailer.

Chapter 7

TECHNICAL DATA

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

PROPERTIES

Anhydrous Sodium Hydroxide

Molecular Weight	40.005
Melting Range	590 to 608°F (310 to 320°C)
Boiling Point	2534°F (1390°C)
Specific Gravity of Pure Solid	2.130
Refractive Index	1.3576
Heat of Fusion	72 Btu/lb 40.0 cal/g
Specific Heat at 20°C	0.48 Btu/(lb) (°F) 0.48 cal/(g) (°C)
Solubility in Water at 0°C at 100°C	42 g/100 g water 347 g/100 g water

Chemical Reactivity

Caustic soda, either dry or in solution, is not combustible; has no flash point, no autoignition temperature, and no explosive limits.

Anhydrous caustic soda is deliquescent (dissolving in moisture absorbed from the atmosphere) and reacts with carbon dioxide in the air to form sodium carbonate. Conversion is 100 percent after prolonged exposure. Therefore, minimum exposure to air is desirable in handling anhydrous forms. On the other hand, the hygroscopic nature of anhydrous caustic soda makes it useful as a drying agent.

Solutions of caustic soda are strongly alkaline and have a high pH or high concentration of negatively charged hydroxyl ions, OH⁻. The high reactivity of caustic soda with many organic and inorganic substances, including certain metals is the main reason for its importance as a basic chemical.

Hydration


Anhydrous caustic soda is a white translucent solid with a fibrous crystalline structure. Being hygroscopic, it attracts water molecules and forms hydrates. Six hydrates of caustic soda have been identified, each with its own distinctive crystalline structure. The number of water molecules attached to each molecule of sodium hydroxide, corresponding to the six hydrated forms, is 7, 5, 4, 3½, 2 or 1. This degree of hydration depends upon the temperature and concentration of the solution in which the crystals form, as shown in the diagram on the facing page. The curve shows the freezing points of solutions with different concentrations; the eutectic solution is just less than 19 percent.

Caustic Soda Solutions

	50 Percent Solution	73 Percent Solution
Melting Range (crystallization begins)	41 to 51°F (5 to 11°C)	140 to 143°F (60 to 62°C)
Solidification Point	41°F (5°C)	140°F (60°C)

NaOH

Freezing Points of Caustic Soda Solutions



Derived from "International Critical Tables," Volume IV, page 235, and PPG Industries laboratories.

TECHNICAL DATA


Specific Gravity of Caustic Soda Solutions* At Various Temperatures

Percent NaOH	32°F 0°C	50°F 10°C	68°F 20°C	86°F 30°C	104°F 40°C	122°F 50°C	140°F 60°C	176°F 80°C	194°F 90°C	212°F 100°C
2	1.024	1.023	1.021	1.018	1.014	1.010	1.004	0.993	0.987	0.980
4	1.048	1.046	1.043	1.039	1.035	1.031	1.025	1.014	1.008	1.001
6	1.071	1.068	1.065	1.061	1.056	1.052	1.046	1.035	1.028	1.022
8	1.094	1.091	1.087	1.083	1.078	1.073	1.068	1.056	1.050	1.043
10	1.117	1.113	1.109	1.104	1.100	1.094	1.089	1.077	1.071	1.064
12	1.140	1.136	1.131	1.126	1.121	1.116	1.110	1.098	1.092	1.086
14	1.162	1.158	1.153	1.148	1.143	1.137	1.132	1.120	1.113	1.107
16	1.185	1.180	1.175	1.170	1.165	1.159	1.153	1.141	1.134	1.128
18	1.207	1.202	1.197	1.192	1.186	1.181	1.175	1.162	1.156	1.149
20	1.230	1.224	1.219	1.214	1.208	1.202	1.196	1.183	1.177	1.170
22	1.252	1.247	1.241	1.235	1.230	1.224	1.217	1.205	1.198	1.191
24	1.274	1.269	1.263	1.257	1.251	1.245	1.239	1.226	1.219	1.212
26	1.296	1.291	1.285	1.279	1.273	1.267	1.260	1.247	1.241	1.234
28	1.318	1.312	1.306	1.300	1.294	1.288	1.281	1.268	1.262	1.255
30	1.334	1.328	1.322	1.315	1.309	1.302	1.289	1.282	1.276
32	1.355	1.349	1.343	1.336	1.330	1.323	1.310	1.303	1.296
34	1.370	1.363	1.357	1.350	1.343	1.330	1.323	1.316
36	1.390	1.384	1.377	1.370	1.363	1.350	1.343	1.336
38	1.410	1.404	1.397	1.390	1.383	1.370	1.363	1.356
40	1.430	1.423	1.416	1.410	1.403	1.389	1.382	1.375
42	1.449	1.443	1.436	1.429	1.422	1.408	1.401	1.394
44	1.468	1.462	1.455	1.448	1.441	1.427	1.420	1.413
46	1.487	1.481	1.473	1.466	1.459	1.445	1.438	1.432
48	1.506	1.500	1.492	1.485	1.478	1.464	1.457	1.450
50	1.525	1.518	1.511	1.504	1.497	1.483	1.476	1.470
52	1.537	1.530	1.524	1.517	1.503	1.496	1.490
54	1.549	1.543	1.536	1.523	1.516	1.510
56	1.568	1.562	1.556	1.543	1.536	1.530
58	1.581	1.575	1.563	1.556	1.550
60	1.597	1.583	1.576	1.570
62	1.603	1.596	1.590
64	1.623	1.616	1.610
66	1.643	1.636	1.630
68	1.663	1.656	1.650
70	1.683	1.676	1.670
72	1.703	1.696	1.690
74	1.723	1.716	1.710

*These values are for pure sodium hydroxide in distilled water. Data below 50 percent were derived from "International Critical Tables," Volume III, page 79. Data above 50 percent were obtained by extrapolation.

NaOH

Specific Gravity of Caustic Soda Solutions*



*These values are for pure sodium hydroxide in distilled water. Data below 50 percent were derived from "International Critical Tables," Volume III, page 79. Data above 50 percent were obtained by extrapolation.

TECHNICAL DATA

Specific Gravity of Mercury Cell and Rayon Grade Caustic Soda Solutions* —In Range from 50.6 to 52.1%

° F	Percent NaOH, 76% Na ₂ O Basis (This is the billing basis described on page 11.)															
	50.6	50.7	50.8	50.9	51.0	51.1	51.2	51.3	51.4	51.5	51.6	51.7	51.8	51.9	52.0	52.1
76	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.531	1.532	1.533	1.534
78	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.531	1.532	1.533
80	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.531	1.532	1.533
82	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.531	1.532
84	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.531
86	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530
88	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529
90	1.514	1.515	1.516	1.516	1.517	1.518	1.520	1.520	1.521	1.522	1.523	1.524	1.526	1.527	1.527	1.528
92	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528
94	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527
96	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526
98	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525
100	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524
102	1.509	1.510	1.511	1.512	1.512	1.514	1.515	1.516	1.516	1.517	1.519	1.520	1.520	1.521	1.522	1.523
104	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523
106	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522
108	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521
110	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520
112	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519
114	1.504	1.505	1.506	1.507	1.507	1.508	1.510	1.511	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518
116	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518
118	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517
120	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516
122	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515
124	1.500	1.500	1.502	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514
126	1.499	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.507	1.509	1.510	1.511	1.512	1.513	1.514
128	1.498	1.499	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513
130	1.497	1.498	1.499	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512
132	1.496	1.497	1.498	1.499	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511
134	1.495	1.496	1.497	1.498	1.499	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510
136	1.495	1.495	1.497	1.498	1.499	1.500	1.500	1.502	1.502	1.503	1.505	1.505	1.506	1.507	1.508	1.509
138	1.494	1.495	1.496	1.497	1.498	1.499	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.507	1.508
140	1.493	1.494	1.495	1.496	1.497	1.498	1.499	1.500	1.501	1.502	1.503	1.504	1.505	1.506	1.507	1.508

*The specific gravity values in this table do not correlate with those on page 36, which are based on pure sodium hydroxide in distilled water. In contrast, the values on this page are on a 76 percent Na₂O basis, which includes sodium carbonate, as explained in detail on page 11.

Specific Gravity of Standard and Low-Iron Grade Caustic Soda Solutions* —In Range from 50.6 to 52.1%

°F	Percent NaOH, 76% Na ₂ O Basis (This is the billing basis described on page 11.)															
	50.6	50.7	50.8	50.9	51.0	51.1	51.2	51.3	51.4	51.5	51.6	51.7	51.8	51.9	52.0	52.1
76	1.526	1.527	1.529	1.530	1.531	1.532	1.533	1.534	1.535	1.536	1.537	1.537	1.538	1.539	1.540	1.541
78	1.525	1.527	1.528	1.529	1.531	1.532	1.532	1.533	1.534	1.535	1.536	1.537	1.538	1.539	1.540	1.541
80	1.525	1.526	1.527	1.529	1.530	1.531	1.531	1.533	1.534	1.534	1.535	1.536	1.537	1.538	1.539	1.540
82	1.524	1.525	1.527	1.528	1.529	1.530	1.531	1.532	1.533	1.534	1.534	1.535	1.536	1.537	1.538	1.539
84	1.523	1.524	1.526	1.527	1.528	1.529	1.530	1.531	1.532	1.533	1.534	1.534	1.535	1.536	1.537	1.538
86	1.522	1.524	1.525	1.526	1.528	1.529	1.529	1.530	1.531	1.532	1.533	1.534	1.535	1.536	1.537	1.537
88	1.522	1.523	1.524	1.525	1.527	1.528	1.528	1.530	1.530	1.531	1.532	1.533	1.534	1.535	1.536	1.537
90	1.521	1.522	1.523	1.525	1.526	1.527	1.528	1.529	1.530	1.530	1.531	1.532	1.533	1.534	1.535	1.536
92	1.520	1.521	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.530	1.531	1.532	1.533	1.534	1.535
94	1.519	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.531	1.532	1.533	1.534	1.534
96	1.518	1.520	1.521	1.522	1.524	1.525	1.525	1.526	1.527	1.528	1.529	1.530	1.531	1.532	1.533	1.534
98	1.518	1.519	1.520	1.522	1.523	1.524	1.525	1.526	1.527	1.527	1.528	1.529	1.530	1.531	1.532	1.533
100	1.517	1.518	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.527	1.528	1.529	1.530	1.531	1.532
102	1.516	1.517	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.530	1.531
104	1.515	1.517	1.518	1.519	1.521	1.522	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530	1.531
106	1.515	1.516	1.517	1.519	1.520	1.521	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.530
108	1.514	1.515	1.516	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527	1.528	1.529	1.529
110	1.513	1.514	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.523	1.524	1.525	1.526	1.527	1.528
112	1.512	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.524	1.526	1.527	1.527
114	1.511	1.513	1.514	1.515	1.517	1.518	1.518	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526	1.527
116	1.511	1.512	1.513	1.515	1.516	1.517	1.518	1.519	1.519	1.520	1.521	1.522	1.523	1.524	1.525	1.526
118	1.510	1.511	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.520	1.521	1.522	1.523	1.524	1.525
120	1.509	1.510	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.520	1.521	1.522	1.523	1.524
122	1.508	1.510	1.511	1.512	1.514	1.515	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523	1.524
124	1.508	1.509	1.510	1.512	1.513	1.514	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522	1.523
126	1.507	1.508	1.510	1.511	1.512	1.513	1.514	1.515	1.515	1.516	1.517	1.518	1.519	1.520	1.521	1.522
128	1.506	1.507	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.516	1.517	1.518	1.519	1.520	1.521
130	1.505	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520	1.520
132	1.504	1.506	1.507	1.508	1.510	1.511	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519	1.520
134	1.504	1.505	1.506	1.508	1.509	1.510	1.511	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518	1.519
136	1.503	1.504	1.506	1.507	1.508	1.509	1.510	1.511	1.511	1.512	1.513	1.514	1.515	1.516	1.517	1.518
138	1.502	1.503	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.513	1.514	1.515	1.517	1.517
140	1.501	1.503	1.504	1.505	1.506	1.507	1.508	1.509	1.510	1.511	1.512	1.513	1.514	1.515	1.516	1.517

*The specific gravity values in this table do not correlate with those on page 36, which are based on pure sodium hydroxide in distilled water. In contrast, the values on this page are on a 76 percent Na₂O basis, which includes sodium carbonate, as explained in detail on page 11. Furthermore, the standard and low-iron grade caustic soda solutions contain over two percent sodium chloride on a 100% NaOH basis.

TECHNICAL DATA

Density of Caustic Soda Solutions at 60 Degrees Fahrenheit


Percent NaOH	Percent Na ₂ O	Specific Gravity 60/60°F	American Standard Baumé Degrees	Degrees Twaddell	Grams NaOH Per Liter	Pounds NaOH		Pounds of Solution	
						Per Gallon	Per Cubic Foot	Per Gallon	Per Cubic Foot
2	1.55	1.023	3.26	4.6	21	0.17	1.28	8.53	63.80
4	3.10	1.045	6.24	9.0	42	0.35	2.60	8.71	65.18
6	4.65	1.067	9.10	13.4	64	0.53	3.99	8.90	66.55
8	6.20	1.090	11.97	18.0	87	0.73	5.44	9.09	67.98
10	7.75	1.112	14.60	22.4	111	0.93	6.94	9.27	69.36
12	9.30	1.134	18.13	26.8	136	1.13	8.49	9.45	70.74
14	10.85	1.156	19.57	31.2	162	1.35	10.09	9.63	72.10
16	12.40	1.178	21.91	35.6	188	1.57	11.76	9.82	73.47
18	13.95	1.201	23.27	40.2	215	1.80	13.44	10.01	74.91
20	15.50	1.223	26.44	44.6	244	2.04	15.26	10.20	76.28
22	17.05	1.245	28.53	49.0	274	2.28	17.08	10.38	77.65
24	18.60	1.267	30.66	53.4	304	2.53	18.96	10.56	79.02
26	20.15	1.289	32.51	57.8	335	2.79	20.90	10.75	80.39
28	21.70	1.310	34.31	62.0	366	3.06	22.88	10.92	81.70
30	23.25	1.332	36.14	66.4	399	3.33	24.92	11.11	83.08
32	24.80	1.353	37.83	70.6	433	3.61	27.00	11.28	84.39
34	26.35	1.374	39.47	74.8	467	3.89	29.14	11.46	85.71
36	27.90	1.394	40.98	78.8	501	4.18	31.30	11.62	86.95
38	29.45	1.415	42.53	83.0	537	4.48	33.53	11.80	88.25
40	31.00	1.434	43.88	86.8	573	4.78	35.78	11.96	89.45
42	32.55	1.454	45.28	90.8	610	5.09	38.09	12.12	90.70
44	34.10	1.473	46.66	94.6	648	5.40	40.42	12.28	91.87
46	35.65	1.492	47.82	98.4	686	5.72	42.81	12.44	93.06
48	37.20	1.511	49.04	102.2	725	6.04	45.24	12.60	94.24
50	38.75	1.530	50.23	106.0	764	6.38	47.72	12.76	95.43
52	40.30	1.549	51.39	109.8	805	6.71	50.24	12.92	96.62

Density of Caustic Soda Solutions at 212 Degrees Fahrenheit

Percent NaOH	Percent Na ₂ O	Specific Gravity 212/60°F	American Standard Baumé Degrees	Degrees Twaddell	Grams NaOH Per Liter	Pounds NaOH		Pounds of Solution	
						Per Gallon	Per Cubic Foot	Per Gallon	Per Cubic Foot
52	40.30	1.49	47.68	98	774	6.46	48.32	12.42	92.93
54	41.85	1.51	48.97	102	815	6.80	50.86	12.59	94.18
56	43.40	1.53	50.23	106	856	7.15	53.44	12.76	95.43
58	44.95	1.55	51.45	110	898	7.49	56.07	12.92	96.67
60	46.50	1.57	52.64	114	941	7.85	58.75	13.09	97.92
62	48.05	1.59	53.81	118	985	8.22	61.49	13.26	99.17
64	49.60	1.61	54.94	122	1030	8.59	64.27	13.42	100.42
66	51.15	1.63	56.04	126	1075	8.97	67.10	13.59	101.66
68	52.70	1.65	57.12	130	1121	9.36	69.98	13.76	102.91
70	54.25	1.67	58.17	134	1168	9.74	72.91	13.92	104.16
72	55.80	1.69	59.20	138	1216	10.14	75.90	14.09	105.41
74	57.35	1.71	60.20	142	1264	10.55	78.92	14.26	106.65

NaOH

Boiling Points of Caustic Soda Solutions At Standard Atmospheric Pressure



Derived from "International Critical Tables," Volume III, page 326, and PPG Industries laboratories.

TECHNICAL DATA


Viscosity of Caustic Soda Solutions

Percent NaOH	Viscosity, centipoises					
	68°F 20°C	86°F 30°C	104°F 40°C	122°F 50°C	140°F 60°C	158°F 70°C
2	1.10	0.90	0.72	0.62	0.52	0.44
4	1.28	1.02	0.82	0.69	0.59	0.49
6	1.48	1.18	0.94	0.77	0.66	0.55
8	1.69	1.32	1.07	0.88	0.74	0.62
10	1.92	1.50	1.21	0.99	0.83	0.70
12	2.2	1.7	1.4	1.1	0.9	0.8
14	2.7	2.0	1.6	1.3	1.0	0.9
16	3.2	2.3	1.8	1.5	1.2	1.0
18	3.8	2.7	2.1	1.7	1.4	1.2
20	4.4	3.3	2.3	2.0	1.6	1.3
22	5.6	3.9	2.8	2.3	1.9	1.5
24	7.0	4.6	3.3	2.7	2.1	1.8
26	8.8	5.6	4.0	3.2	2.5	2.0
28	11.0	6.8	4.9	3.7	2.8	2.3
30	13.4	8.6	5.9	4.4	3.2	2.6
32	17.0	10.3	7.0	5.0	3.7	2.9
34	20.6	12.5	8.2	5.8	4.2	3.3
36	25.5	14.5	9.8	6.7	4.7	3.7
38	31.0	17.3	11.2	7.5	5.4	4.1
40	36.0	20.3	12.6	8.4	6.0	4.5
42	44.0	23.5	14.7	9.8	6.6	5.0
44	52.0	27.0	16.5	10.6	7.4	5.5
46	60.0	31.0	18.5	11.8	8.2	6.0
48	70.0	35.0	20.2	13.0	9.0	6.5
50	78.3	39.5	22.1	14.0	9.7	7.1


6.2 gal 803 gal
min 8.3 gal

NaOH

Viscosity of Caustic Soda Solutions



TECHNICAL DATA



Viscosity of Caustic Soda Solutions

Percent NaOH	Viscosity, centipoises					
	140°F 60°C	180°F 82°C	220°F 104°C	260°F 127°C	300°F 149°C	340°F 171°C
50	10.0	4.8	2.6	1.5	Vapor	Vapor
60	16.7	7.9	4.3	2.5	1.5	Vapor
70	Solid	13.0	6.5	3.6	2.0	1.3
75	Solid	16.7	8.0	4.4	2.5	1.5


Specific Heat of Caustic Soda Solutions

Percent NaOH	Specific Heat, Btu per Pound per Degree Fahrenheit															
	32°F	40°F	50°F	60°F	80°F	100°F	120°F	140°F	160°F	180°F	200°F	220°F	240°F	260°F	280°F	300°F
0	1.004	1.003	1.001	0.999	0.998	0.997	0.998	0.999	1.000	1.002	1.004
2	0.965	0.967	0.968	0.969	0.972	0.974	0.977	0.978	0.980	0.983	0.986
4	0.936	0.940	0.943	0.946	0.951	0.954	0.957	0.960	0.962	0.965	0.966
6	0.914	0.920	0.924	0.928	0.933	0.938	0.941	0.944	0.946	0.948	0.950
8	0.897	0.902	0.907	0.911	0.918	0.923	0.927	0.930	0.932	0.934	0.936
10	0.882	0.888	0.893	0.897	0.905	0.911	0.916	0.918	0.920	0.922	0.923
12	0.870	0.877	0.883	0.887	0.894	0.901	0.906	0.909	0.911	0.912	0.913
14	0.861	0.868	0.874	0.879	0.886	0.892	0.897	0.901	0.903	0.903	0.904
16	0.853	0.860	0.866	0.871	0.880	0.886	0.891	0.894	0.896	0.897	0.897
18	0.847	0.854	0.860	0.865	0.873	0.880	0.885	0.888	0.890	0.891	0.891
20	0.842	0.848	0.854	0.859	0.868	0.875	0.880	0.884	0.886	0.886	0.887
22	0.837	0.844	0.849	0.854	0.863	0.870	0.876	0.880	0.882	0.882	0.883
24	0.839	0.844	0.849	0.858	0.866	0.873	0.877	0.879	0.879	0.880
26	0.835	0.840	0.845	0.854	0.863	0.869	0.874	0.875	0.876	0.876
28	0.830	0.836	0.841	0.850	0.859	0.866	0.870	0.872	0.872	0.873
30	0.826	0.832	0.837	0.846	0.855	0.862	0.866	0.868	0.869	0.869
32	0.822	0.828	0.833	0.842	0.850	0.857	0.862	0.863	0.864	0.864
34	0.823	0.828	0.837	0.845	0.852	0.856	0.857	0.858	0.858
36	0.819	0.824	0.832	0.840	0.845	0.849	0.850	0.851	0.851
38	0.816	0.820	0.827	0.833	0.837	0.841	0.842	0.842	0.843
40	0.812	0.815	0.821	0.826	0.829	0.831	0.832	0.832	0.832
42	0.807	0.809	0.813	0.816	0.819	0.819	0.820	0.820	0.820
44	0.802	0.804	0.806	0.807	0.807	0.807	0.806	0.804
46	0.793	0.794	0.795	0.794	0.794	0.793	0.791	0.789
48	0.783	0.782	0.781	0.780	0.779	0.777	0.776
50	0.771	0.769	0.768	0.767	0.765	0.765	0.764	0.763	0.762	0.762	0.761	0.761
52	0.759	0.757	0.756	0.754	0.753	0.752	0.751	0.749	0.748	0.747	0.746	0.745
54	0.746	0.744	0.741	0.739	0.739	0.738	0.737	0.735	0.733	0.731	0.730	0.728
56	0.733	0.730	0.728	0.726	0.724	0.723	0.722	0.721	0.719	0.717	0.715	0.713
58	0.719	0.717	0.715	0.713	0.711	0.709	0.707	0.705	0.703	0.702	0.700
60	0.706	0.705	0.703	0.701	0.699	0.697	0.695	0.693	0.691	0.690	0.688
62	0.694	0.692	0.690	0.688	0.687	0.685	0.683	0.681	0.679	0.677
64	0.684	0.682	0.681	0.679	0.677	0.675	0.673	0.671	0.670	0.668
66	0.675	0.673	0.671	0.669	0.668	0.666	0.664	0.662	0.660	0.658
68	0.663	0.662	0.660	0.658	0.656	0.655	0.653	0.651	0.649
70	0.655	0.653	0.651	0.649	0.647	0.646	0.644	0.642	0.640
72	0.645	0.643	0.641	0.639	0.637	0.635	0.634	0.632
74	0.635	0.633	0.631	0.629	0.628	0.626	0.624
76	0.628	0.627	0.625	0.623	0.621	0.619	0.617
78	0.620	0.618	0.616	0.615	0.613	0.611

Derived from data of Bertetti and McCabe, "Industrial Engineering Chemistry," Volume 28, page 378, and McCabe and Wilson, "Industrial Engineering Chemistry," Volume 34, page 558.

TECHNICAL DATA

Specific Heat of Caustic Soda Solutions



Derived from data of Bertetti and McCabe, "Industrial Engineering Chemistry," Volume 28, page 378, and McCabe and Wilson, "Industrial Engineering Chemistry," Volume 34, page 558.

HOW TO USE HEAT CONTENT (ENTHALPY) CHART

Use of the chart on the facing page simplifies the calculation of many problems frequently encountered in diluting, cooling or heating caustic soda solutions such as:

1. How to determine the temperature of the final solution resulting from the dilution of a caustic soda solution, assuming no heat loss.
2. How to determine the amount of heat to remove from or add to a caustic soda solution to change its temperature a desired number of degrees.

Examples

PROBLEM 1:

What will be the temperature of a 50 percent caustic soda solution prepared by diluting a 73 percent solution at 200°F with water at 80°F?

SOLUTION:

Draw a straight line between these two points on the chart: (1) the intersection of the 73 percent caustic soda line and the 200°F curve, and (2) the intersection of the 0 percent caustic soda line and the 80°F curve. The line drawn crosses the 50 percent caustic soda line at 263°F, which is the answer.


PROBLEM 2:

How many Btu per pound of solution must be removed to cool a 50 percent caustic soda solution from 263°F to 120°F?

SOLUTION:


The relative heat contents of a 50 percent caustic soda solution at 263°F and at 120°F appear on the chart at the 272 and 162 heat content lines respectively. The difference between these heat content values, 100 Btu per pound of solution, is the answer.

NaOH



Derived from data of Bertetti and McCabe, "Industrial Engineering Chemistry," Volume 28, page 378, and McCabe and Wilson, "Industrial Engineering Chemistry," Volume 34, page 558.


TECHNICAL DATA



NaOH

Dilution Temperatures of Anhydrous Caustic Soda

Based on Anhydrous Caustic Soda at 77°F



TECHNICAL DATA

HOW TO USE CHART FOR DILUTING AND MIXING CAUSTIC SODA SOLUTIONS

Use of the chart on the facing page simplifies the calculation of problems such as:

1. How much water is needed to dilute a strong caustic soda solution to a weaker one?
2. How many gallons of strong solution are needed to bring a weak solution to a higher concentration?
3. What is the strength of a solution formed by mixing equal volumes of water and a caustic soda solution?

The left-hand line of the chart, zero percent, is of course water. The decreasing heights from left to right of the vertical lines for percentage concentration reflect the greater weight per gallon of stronger solutions. The chart does not take into consideration differences in initial temperatures of solutions and water as well as volumetric changes caused by heat of dilution since these conditions usually have relatively small effects on final volume.

Examples

PROBLEM 1 (a):

How many gallons of water should be added to dilute 16,000 gallons of 73 percent caustic soda solution to 50 percent?

SOLUTION:

Draw a line from zero percent on the weak solution scale at top to 73 percent on the strong solution scale

at bottom. From the point where the drawn line intersects the 50 percent vertical line, read 44 gallons of weak solution needed at right and 56 gallons of strong solution needed at left.

Multiply the percentage ratio,

$$\frac{44 \text{ gallons weak solution}}{56 \text{ gallons strong solution}} \times 16,000 \text{ gallons strong solution} = 12,571 \text{ gallons weak solution}$$

The answer is the number of gallons of water to be added.

PROBLEM 1 (b):

How many gallons of water should be added to dilute 1,000 gallons of 50 percent caustic soda solution to 19 percent? (The latter concentration has the lowest freezing point and can withstand storage temperatures down to approximately -18°F.)

SOLUTION:

Draw a line from zero percent on the weak solution scale at top to 50 percent on the strong solution scale at bottom. From the point where the drawn line intersects the 19 percent vertical line, read 70 gallons of weak solution needed at right and 30 gallons of strong solution needed at left.

Multiply the percentage ratio,

$$\frac{70 \text{ gallons weak solution}}{30 \text{ gallons strong solution}} \times 1,000 \text{ gallons strong solution} = 2,333 \text{ gallons weak solution}$$

The answer is the number of gallons of water to be added.

PROBLEM 2:

How many gallons of 50 percent caustic soda solution should be added to 300 gallons of 10 percent solution to obtain a final solution of 18 percent concentration?

SOLUTION:

Draw a line from 10 percent on the weak solution scale at top to 50 percent on the strong solution scale at bottom. From the point where the drawn line intersects the 18 percent vertical line, read 84 gallons of weak solution needed at right and 16 gallons of strong solution needed at left.

Multiply the percentage ratio,

$$\frac{16 \text{ gallons strong solution}}{84 \text{ gallons weak solution}} \times 300 \text{ gallons weak solution} = 57 \text{ gallons strong solution}$$

The answer is the number of gallons of 50 percent caustic soda solution to be added.

PROBLEM 3:


What is the strength of the solution formed by mixing 10,000 gallons of 40 percent caustic soda solution with 10,000 gallons of water?

SOLUTION:

Draw a line from zero percent on the weak solution scale at top to 40 percent on the strong solution scale at bottom. The horizontal line connecting 50 on both left and right scales represents the 50:50 percentage ratio of the 10,000-gallon volumes stated in the problem. The drawn line intersects the horizontal ratio line at the 23 percent vertical line, which is the concentration of the final solution.


NaOH

Diluting and Mixing Caustic Soda Solutions



Equivalence of Sodium Oxide (Na_2O), Caustic Soda (NaOH) and Soda Ash (Na_2CO_3)

Na ₂ O	NaOH	1	7748	1	3249	26	2015	3445	51	3952	6757	5888	10069	10202	10334	10467	10599	10732	10864	10997	11129	11262	11394	11527	11659	11792	11924	12057	12189	12322	12454	12587		
	Na ₂ O	6	465	795	2402	4107	4240	4339	56	7419	7552	81	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	7438	7571	7704	7836	7969		
	Na ₂ CO ₃	21	1627	2782	3564	6094	71	5501	5501	9407	9539	96	96	97	98	99	100	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518		
	NaOH	15	1162	1987	3099	5300	66	5114	5191	8877	9009	92	93	94	95	96	97	7051	7128	7206	7283	7361	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	
	Na ₂ O	13	1007	1722	2944	5035	63	4881	4959	8479	8347	88	88	87	86	85	84	6973	7051	7128	7206	7283	7361	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210
	Na ₂ CO ₃	23	1782	3047	4642	6227	73	5579	5579	9539	9539	96	96	97	98	99	100	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518	8595	
	NaOH	18	1395	2385	3332	4254	5565	66	5114	5191	8877	9009	92	93	94	95	96	7051	7128	7206	7283	7361	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287
	Na ₂ O	16	1240	2120	3177	5432	66	5114	5191	8877	9009	92	93	94	95	96	97	7051	7128	7206	7283	7361	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287
	Na ₂ CO ₃	25	1937	3312	4642	6227	73	5579	5579	9539	9539	96	96	97	98	99	100	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518	8595	
	NaOH	24	1860	3180	4642	6227	73	5579	5579	9539	9539	96	96	97	98	99	100	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518	8595	
Na ₂ O	23	1782	3047	4642	6227	73	5579	5579	9539	9539	96	96	97	98	99	100	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518	8595		
Na ₂ CO ₃	22	1705	2914	3642	4642	5501	71	5501	5501	9407	9539	96	96	97	98	99	100	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518	8595	
NaOH	21	1627	2782	3564	6094	71	5501	5501	9407	9539	96	96	97	98	99	100	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518	8595		
Na ₂ O	20	1550	2650	3487	5962	70	5424	5424	9274	9274	93	94	95	96	97	98	99	7438	7516	7593	7671	7748	7825	7902	7979	8056	8133	8210	8287	8364	8441	8518	8595	
Na ₂ CO ₃																																		



Equations for Converting Hydrometer Readings Of Liquids Heavier Than Water

AMERICAN STANDARD BAUMÉ:

$$\text{Specific Gravity} = \frac{145}{145 - ^\circ\text{Bé}}$$

$$^\circ\text{Bé} = \frac{145(\text{sp gr} - 1)}{\text{sp gr}}$$

TWADDELL:

$$\text{Specific Gravity} = \frac{(0.5 \times ^\circ\text{Tw}) + 100}{100}$$

$$^\circ\text{Tw} = (\text{sp gr} - 1)200$$

Chapter 8

METHODS OF ANALYSIS

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

The analytical methods presented here were selected on the basis of their ability to provide the most accurate results consistent with simplicity of equipment and acceptable analytical practices. Many of the techniques were developed in PPG Industries laboratories as improvements on classical methods. The procedures apply to both solution and anhydrous forms of caustic soda. The applicability to various PPG grades is listed under each method.

The laboratories of the Chemicals Group of PPG Industries customarily determine trace elements in caustic soda by optical emission spectrography and spectrophotometric procedures. PPG personnel will gladly provide detailed information on

analytical procedures and techniques for determining certain trace substances not listed here.

Analytical determinations for the following substances appear in this chapter:

Sodium hydroxide and total alkalinity	54
Sodium carbonate (low concentrations)	56
Sodium chloride	58
Sodium chloride (low concentrations)	59
Sodium sulfate	60
Sodium sulfate (low concentrations)	60
Sodium chlorate	61
Sodium chlorate (low concentrations)	62
Iron	64

PPG practice is to report % NaOH and % Na₂O on an "as is" basis, but all other compounds and metals on an "A.B." or anhydrous caustic soda basis so that a ready comparison can be made between 50 percent and 73 percent solutions.

DETERMINATION OF SODIUM HYDROXIDE (NaOH), SODIUM CARBONATE (Na₂CO₃) AND SODIUM OXIDE (Na₂O)—TOTAL ALKALINITY

Double End Point Titration Method

Abstract

This method involves titration of the caustic soda sample by a dual end point titration technique, first to the phenolphthalein end point and then to the methyl orange-xylene cyanole end point. The alkali components are calculated from the titration data.

Application

NaOH, Na₂CO₃ and Na₂O in standard, low-iron and rayon grade caustic soda.

NaOH and Na₂O only in mercury cell grade. Na₂CO₃ in mercury cell grade is determined separately by the CO₂ evolution-conductometric method on page 56.

Precision

The precision of the method is $\pm 0.10\%$ NaOH, Na₂CO₃ and Na₂O by weight.

Reagents

Standard 1.0N hydrochloric acid solution
Phenolphthalein indicator solution
Methyl orange-xylene cyanole indicator solution




Testing for trace metal content of caustic soda with atomic absorption spectrophotometer.

Procedure

Weigh a sample equivalent to approximately 2.0 g of anhydrous sodium hydroxide to 0.1 mg into a tared 10 ml Teflon or glass weighing bottle and stopper.

Measure approximately 40 ml of 1.0N hydrochloric acid solution (slightly less than the neutralization requirement of the sample) with a burette into a 250 ml beaker. Carefully remove the stopper from the weighing bottle and cautiously submerge both the stopper and weighing bottle in the acid solution. With the aid of a stirring rod, carefully manipulate the weighing bottle in such a manner that it is inverted with no air bubbles existing in the bottle until all the caustic is dissolved. Permit the bottle and stopper to remain in the beaker during the titration.



Volumetric burette for total alkalinity determination.

Add 2 drops of phenolphthalein indicator solution and continue titration with standard 1.0N hydrochloric acid solution from the burette until the pink color begins to fade.

Swirl the weighing bottle in the solution and carefully continue the titration to a colorless end point. Record the total volume of acid used in this titration (phenolphthalein end point) to the nearest 0.01 ml as value "A."

Add 2 drops of methyl orange-xylene cyanole indicator solution and continue titration to the steel-gray end point. Record the volume of acid used in the total titration to the nearest 0.01 ml as value "B."

Record the temperature of the acid used for titration and correct the volumes (values "A" and "B") to 20° C (see Temperature Correction Table, page 65).

Calculation

$$\% \text{ NaOH by weight} = \frac{[A - (B - A)] \times N \times 0.040 \times 100}{\text{Weight of Sample (as received)}}$$

$$\% \text{ Na}_2\text{O by weight} = \frac{B \times N \times 0.031 \times 100}{\text{Weight of Sample (as received)}}$$

$$\% \text{ Na}_2\text{CO}_3 \text{ by weight} = \frac{2(B - A) \times N \times 0.053 \times 100}{\text{Weight of Sample (as received)}}$$

$$\% \text{ Na}_2\text{CO}_3, \text{ A.B.*} = \frac{\% \text{ Na}_2\text{CO}_3 \text{ by weight} \times 100}{\% \text{ NaOH by weight}}$$

Preparation of Reagents and Solutions

1. HYDROCHLORIC ACID 1.0N:

Dilute 83 ml of reagent grade concentrated hydrochloric acid, specific gravity 1.19, with distilled water to 1 liter in a volumetric flask and mix thoroughly.

Standardization: Weigh 2 ± 0.1 g of anhydrous sodium carbonate (primary standard) to 0.1 mg into a 250 ml wide mouth Erlenmeyer flask, dissolve in 15 to 20 ml of distilled water, and add 2 drops of methyl orange-xylene cyanole indicator solution. Titrate with approximately 1.0N hydrochloric acid to the end point.

$$\text{Normality (N) of the HCl} = \frac{\text{g Na}_2\text{CO}_3 \times 1000}{53.00 \times \text{ml HCl used}}$$

2. METHYL ORANGE-XYLENE CYANOLE INDICATOR SOLUTION:

Dissolve 1.33 g of methyl orange and 3.00 g of xylene cyanole separately in distilled water. Mix them together when they are dissolved and dilute to 1 liter with distilled water.

Note: With this mixed indicator, alkaline solutions are green, acid solutions are purple-red, and neutral solutions are steel-gray.

Special Equipment

A drawing of the 55 ml burette is shown at the left. The burette contains a 40 ml bulb. Each ml graduation between 40-55 ml is subdivided into 0.1 ml; 1 ml = 1 inch, NBS accuracy. Graduations are blue stripes on white background. The rate of drain is 55 ml per 160-180 seconds.

This burette is made under Sketch No. PPG 40476-G by SGA Scientific, Inc., 735 Broad Street, Bloomfield, NJ 07003, (201) 748-6600.

*Anhydrous NaOH basis.

METHODS OF ANALYSIS

DETERMINATION OF SODIUM CARBONATE (Na_2CO_3)

CO₂ Evolution-

Conductometric Method

Abstract

The method involves the determination of sodium carbonate in caustic soda by conductometric measurement. The method entails the evolution of carbon dioxide from the sample by an acidification and purging process. The liberated carbon dioxide is absorbed in an excess of barium hydroxide solution. The change in electrical conductivity caused by the absorption of carbon dioxide to form barium carbonate is the means by which sodium carbonate is measured.

Application

Mercury cell grade caustic soda

Precision

The precision of the method is $\pm 0.003\%$ Na_2CO_3 by weight.

Special Apparatus and Operation

A conductance bridge is the principle item of special apparatus required for the method. The bridge should be capable of measuring differential resistances of 1 ohm in the desired concentration range.

Other items of apparatus required are common in most laboratories. They are assembled and arranged as shown in the schematic diagram on page 57. The thermostated water bath (33) for regulating and controlling the temperature of the conductivity cell (24) and barium hydroxide reservoir (30) should be of sufficient size and have sufficient capacity to function as a thermal regulator for these two items

of apparatus. The temperature of this environment must be controlled closely. Operation at $33 \pm 0.2^\circ\text{C}$ is recommended in order that precise and accurate results may be obtained by the procedure.

The general procedure first involves purging the system with nitrogen or air (free of carbon dioxide) for about 15 minutes prior to introducing a fresh barium hydroxide sample into the conductivity cell. The proper size sample of caustic soda is then pipetted into the dropping funnel (7) located above the reaction flask (10). The purge stream is attached to the dropping funnel and the sample forced into the reaction flask to provide minimum contamination due to carbon dioxide in the air during the transfer of the sample. The dropping funnel is washed well with distilled water with the aid of the purge stream, and the system is purged until a constant ohm reading is obtained from the conductivity cell. The acid is then introduced into the reaction flask in a similar manner as the sample, and the system is purged continuously for 15 minutes. The reaction flask is heated to 60°C during this period to aid in reducing the solubility of carbon dioxide in the acidified sample.

Analytical Procedure

In this procedure actual conductance or actual resistance of the solutions is measured. Before making any measurements, check the temperature of the water bath and adjust it to 33°C . Clean the conductivity cell (24) with approximately 0.1N hydrochloric acid and rinse thoroughly with distilled water. Position the empty cell equipped with the electrodes and inlet and outlet tubes in the water bath and make the connections shown in the diagram. Purge the system for 15 min-

utes with a slow stream of nitrogen or air freed of carbon dioxide. Purge gas enters at (1) and leaves at (18).

Rinse the conductivity cell with the barium hydroxide solution by manipulation of the stopcocks and application of suction through tube (19).


Fill the conductivity cell with 0.014N barium hydroxide solution to some predetermined mark on the cell. This mark should be inscribed on the cell body so that fillings of the cell can be duplicated. The mark should be located so that the solution fills the cell a little more than halfway.

Add the solution of the weighed sample (equivalent to 6.0 g of anhydrous caustic soda) to the reservoir (7) and force it into the sample flask (10) by connecting the purge stream to the top of funnel (7) and opening stopcock (8). Wash the reservoir with three 15 ml portions of distilled water using the purge for forcing the washings into the reaction chamber. After the last washing, continue to purge the system at a rate of 0.1 standard liters per minute for 3 minutes and record initial ohm reading. Finally introduce 10 ml of dilute (1:1) sulfuric acid into the sample flask by way of the reservoir and purge stream. The sample must be acidified to a $\text{pH} < 3.0$. A 6.0-g sample of caustic soda containing 0.05% sodium carbonate (A.B.*) should provide a differential resistance span of approximately 21 ohms in a conductivity cell with a 0.12 cell constant.

Adjust the purge gas flow to 0.1 standard liters per minute. This operation facilitates the transfer of any liberated carbon dioxide from the sample into the absorber solution through the fritted glass dispersion tube (17). Continue this sweeping operation for 15 minutes. Then check the rate and measure the resistance of the absorber solution with the conductivity bridge.

* Anhydrous NaOH basis.

Apparatus for the Determination of Sodium Carbonate (Na_2CO_3) CO_2 Evolution – Conductometric Method



- | | | |
|--|--|--|
| 1. Nitrogen or Air Source (not shown) | 15. Standard taper ball and socket joint | 27. Stopcock |
| 2. Drying tube charged with Magnesium Perchlorate | 16. Tube delivering liberated CO_2 from sample to conductivity cell (rubber tubing) | 28. Filling tube to charge cell with $\text{Ba}(\text{OH})_2$ |
| 3. Drying tube charged with Ascarite | 17. Fritted glass dispersion tube | 29. Rubber stopper |
| 4. Same as No. 3 | 18. Vent tube (Glass tubing) | 30. Reservoir for storing $\text{Ba}(\text{OH})_2$ solution, 5-l flask, Erlenmeyer |
| 5. Flowmeter | 19. Suction tube for emptying conductivity cell (Glass tubing) | 31. Thermometer |
| 6. Rubber stopper | 20. Liquid trap | 32. Air stirrer |
| 7. 125-ml Separatory funnel | 21. Water aspirator for Vacuum | 33. Water bath |
| 8. Stopcock (Part of No. 7) | 22. Conductivity Bridge | 34. Heating Coil |
| 9. 24/40 ground joint on Separatory funnel (Part of No. 7) | 23. Conductivity electrodes | 35. Thermoregulator |
| 10. 250 ml Separatory funnel | 24. Conductivity cell, 4 oz. bottle, wide mouth | 36. Bath Control |
| 11. Heating tape | 25. Rubber stopper | 37. 115 V Powerstat |
| 12. Stopcock (Part of No. 10) | 26. Standard taper ball and socket joint | 38. Aspirator bulb for pressurizing $\text{Ba}(\text{OH})_2$ reservoir |
| 13. Drain tube for discarding reacted sample | | 39. Drying tube charged with ascarite |
| 14. 115 V Powerstat | | 40. Glass tubing for pressurizing reservoir |

METHODS OF ANALYSIS

Record the value and compute the change in resistance of this solution resulting from the formation of barium carbonate.

For results of greatest accuracy it is desirable to run a blank test with distilled water in place of the sample and make an appropriate blank correction.

When the determination is completed, remove the acidified sample solution by draining through stopcock (12) at the bottom of the flask. Rinse the flask thoroughly with distilled water in preparation for future tests. Remove "spent" barium hydroxide solution from the conductivity cell by suction through connection (19).

Consult the calibration chart (see below) to obtain the number of grams of sodium carbonate in the sample.

Calculation

$$\begin{aligned} & \% \text{Na}_2\text{CO}_3 \text{ by weight} \\ &= \frac{\text{grams Na}_2\text{CO}_3 \text{ from chart} \times 100}{\text{Weight of Sample (as received)}} \\ & \% \text{Na}_2\text{CO}_3, \text{ A.B.*} \\ &= \frac{\text{Weight \% Na CO}_3 \times 100}{\text{Weight \% NaOH in Sample Tested}} \end{aligned}$$

Calibration of Conductivity Apparatus

Measure suitable increments ranging from 1 ml to 10 ml of the standard solution of sodium carbonate (see below) into the sample flask (10) and evolve the carbon dioxide into the absorber solution as described in the procedure above. The same purge rate (0.1 standard liters per minute) should be used in the calibration and in the sample procedure. Prepare a calibration chart for the apparatus from these data, relating the number of grams of sodium carbonate and the resistance span of the absorber solution.

*Anhydrous NaOH basis.

Special Reagents and Solutions

1. STANDARD SOLUTION OF SODIUM CARBONATE:

Dissolve 0.1000 g of reagent grade, anhydrous sodium carbonate in freshly boiled and cooled distilled water and dilute to 100 ml in a volumetric flask. One ml of this solution contains 0.001 g of sodium carbonate.

2. STANDARD BARIUM HYDROXIDE ABSORBER SOLUTION:

Dissolve 18.7 g of reagent grade barium hydroxide in 700 ml of boiling distilled water. After saturation, remove any undissolved solids by filtration and catch the filtrate in a suitably sized reagent bottle containing 6.9 l of distilled water which has previously been purged with a slow stream of nitrogen to expel carbon dioxide. Add a pinch of gelatin, stopper the reagent bottle and mix the solution thoroughly. The concentration of this solution should be about 0.014N and should be checked by titrating an aliquot of it with standardized 0.03N hydrochloric acid.

DETERMINATION OF SODIUM CHLORIDE (NaCl)

Volhard Method

Abstract

The chloride in caustic soda is determined according to the Volhard titration method. The method entails the acidification of the sample with nitric acid and the subsequent titration of the chloride with standard silver nitrate and standard potassium thiocyanate solutions.

Application

Standard, low-iron and rayon grade caustic soda (not applicable to mercury cell grade caustic soda).

Precision

The precision of the method is $\pm 0.10\%$ NaCl by weight.

Reagents

Standard 0.1N silver nitrate solution (corrected to 20° C)

Standard 0.1N potassium thiocyanate solution (corrected to 20° C)

Concentrated nitric acid (C.P.), sp gr 1.42

Ferric nitrate indicator solution

Procedure

Weigh a sample equivalent to approximately 10 g of anhydrous sodium hydroxide to 0.1 g into a 250 ml beaker, and add 35 ml of distilled water. Add 2 ml of ferric nitrate indicator solution and neutralize with concentrated nitric acid till iron precipitate dissolves. Then add 1 to 2 ml excess.

Add 0.2 ml of standard 0.1N potassium thiocyanate from a burette and titrate slowly with standard 0.1N silver nitrate solution until the red color disappears. Then add an excess of at least 2 ml. Stir vigorously until the silver chloride coagulates. Quantitatively filter the sample through a medium-porosity sintered-glass filter to remove the silver chloride precipitate. Wash the precipitate with 5% nitric acid until it is free of silver nitrate. Back-titrate the excess silver nitrate in the filtrate with standard 0.1N potassium thiocyanate solution until a faint rust-colored color persists. Compute the net volume in ml of standard silver nitrate solution consumed.

Calculation

$$\begin{aligned} & \% \text{NaCl by weight} \\ &= \frac{(\text{ml AgNO}_3 \times N) - (\text{ml KCNS} \times N) \times 0.0585 \times 100}{\text{Weight of Sample (as received)}} \\ & \% \text{NaCl, A.B.*} \\ &= \frac{\% \text{NaCl by weight} \times 100}{\% \text{NaOH by weight}} \end{aligned}$$

Preparation of Special Reagents and Solutions

1. PREPARATION AND STANDARDIZATION OF SILVER NITRATE AND POTASSIUM THIOCYANATE:

Preparation of 0.1N Silver Nitrate:

Dissolve 17 g \pm 0.1 g of silver nitrate in distilled water. Add 5.5 ml of concentrated nitric acid and dilute to 1 liter.

Preparation of 0.1N Potassium Thiocyanate: Dissolve 9.78 g \pm 0.1 g potassium thiocyanate (A.R.) in distilled water and dilute to one liter.

If it is desirable to adjust the silver nitrate and potassium thiocyanate to exactly the same normality, titrate a quantity of the potassium thiocyanate with silver nitrate according to the procedure and determine the ratio of standard solution.

$$C = \frac{\text{ml AgNO}_3}{\text{ml KCNS}}$$

To dilute a solution with water:

$$\frac{A - D}{D} \times X = Y$$

To strengthen a weak solution with a stronger solution:

$$\frac{D - A}{C - D} \times Y = X$$

where A = actual concentration of the solution that is to be corrected

D = desired concentration

C = concentration of strengthening solution

X = amount of stronger solution to be added, taken, or prepared

Y = amount of weaker solution or water to be added or taken

*Anhydrous NaOH basis.

Standardization: Dry a small quantity of potassium chloride (A.R.) in the drying oven for 2 hours. Weigh 0.07 grams \pm 0.1 mg of dry, cool potassium chloride into a weighing bottle. Dissolve the potassium chloride in water and wash it into a 250 ml beaker. Titrate according to the general procedure.

AgNO₃ Normality

$$= \frac{\text{Grams KCl}}{0.07456 [\text{ml AgNO}_3 - (\text{ml KCNS}) \times C]}$$

KCNS Normality = AgNO₃ Normality \times C

2. FERRIC NITRATE INDICATOR SOLUTION:

Dissolve 100 g of ferric nitrate (A.R.) in distilled water and add 100 ml nitric acid (C.P.) sp gr 1.42. Dilute to one liter.

Note: For assay work the solutions should be standardized on the day used and the titrant volumes corrected to 20°C per table on page 65.

DETERMINATION OF LOW CONCENTRATIONS OF SODIUM CHLORIDE (NaCl)

Turbidimetric Method

Abstract

The method involves the measurement of low concentrations of sodium chloride by a turbidimetric procedure. The method entails reaction of the acidified sample with an excess of silver nitrate. The resulting turbidity due to silver chloride is determined spectrophotometrically.

Application

Mercury cell grade caustic soda.

Precision

The precision of the method is $\pm 0.002\%$ NaCl by weight.

Reagents

Phenolphthalein indicator solution

Dilute nitric acid (1:1)

Standard silver nitrate solution (0.1N)

Procedure

Weigh a sample equivalent to approximately 5 g of anhydrous sodium hydroxide to 0.1 g into a 250 ml beaker. Dilute the sample with 20 ml of distilled water, chloride-free. Add 1 drop of phenolphthalein indicator solution and neutralize the sample solution cautiously by the addition of dilute (1:1) nitric acid. Render the solution slightly acidic by adding 1 drop of acid in excess.

Transfer the solution to a 100 ml volumetric flask, cool to room temperature, and dilute to the mark with distilled water. Prepare another 100 ml volumetric flask filled to the mark with distilled water containing the same amount of phenolphthalein indicator and excess acid as used in the sample above. This solution serves as a blank.

Add 1 ml of diluted (1:1) nitric acid solution to both the sample and blank solutions in the flasks. Mix thoroughly. Add 1 ml of 0.1N silver nitrate solution to each flask and mix by inverting once only, then set aside in the dark for 15 minutes. The total volume of the sample and standard solutions in the 100 ml flasks is 102.0 ml. It is not necessary to standardize the silver nitrate solution volumetrically for this test.

At the end of the digestion period transfer a sufficient amount of the blank solution to the 5 cm comparison cell of the spectrophotometer and measure the light transmittance of the blank at 425 m μ as compared with distilled water adjusted to 100 percent transmittance at 425 m μ . Record the transmittance value.

METHODS OF ANALYSIS

Repeat this measurement with the prepared sample solution, and record the transmittance value. Compute the grams of chloride in the sample (blank-corrected) from a previously prepared calibration for the spectrophotometer (see below).

Calculation

$$\begin{aligned} & \% \text{ NaCl by weight} \\ &= \frac{\text{Grams of Cl}^- \text{ from Chart} \times 1.6483 \times 100}{\text{Weight of Sample (as received)}} \end{aligned}$$

$$\begin{aligned} & \% \text{ NaCl, A.B.*} \\ &= \frac{\% \text{ NaCl by weight} \times 100}{\% \text{ NaOH by weight}} \end{aligned}$$

Calibration of Spectrophotometer

Standard Chloride Solution:

Weigh 2.1143 grams of oven-dried, reagent-grade potassium chloride and transfer to a 1000 ml volumetric flask. Dissolve the salt in distilled water and dilute to the mark. Mix thoroughly.

Measure a 10 ml aliquot portion of this solution into another 1000 ml volumetric flask and dilute to the mark with distilled water. Mix thoroughly. One ml of the resulting solution contains 0.00001 g of chloride.

Standardization Procedure

Prepare a series of standards by measuring 1.0, 3.0, 5.0 and 10.0 ml of the standard chloride solution respectively into a series of 100 ml volumetric flasks. Dilute each standard to 100 ml with distilled water and mix thoroughly. Proceed with the turbidity development and measurement according to the directions given above for the samples. Conduct the turbidimetric measurements versus distilled water in the reference cell. From these data prepare a calibration curve.

*Anhydrous NaOH basis.

DETERMINATION OF SODIUM SULFATE (Na_2SO_4)

Gravimetric Method

Abstract

The method involves the determination of sulfate present in the caustic soda sample by precipitation as barium sulfate in slightly acidic solution and the subsequent gravimetric determination of the barium sulfate.

Application

Standard, low-iron and rayon grade caustic soda.

Precision

The precision of the method is $\pm 0.02\%$ Na_2SO_4 by weight.

Reagents

Concentrated hydrochloric acid (C.P.), sp gr 1.19

Methyl orange indicator solution

Barium chloride, 10% solution

Silver nitrate, 2% solution

Procedure

Weigh a sample equivalent to 25 g of anhydrous sodium hydroxide to 0.1 g into a 400 ml beaker. Add 200 ml of distilled water, 0.5 ml of methyl orange indicator solution and neutralize with concentrated hydrochloric acid. Adjust the volume to 300 ml with distilled water and add 3 ml of acid in excess. Heat the solution to boiling and add dropwise 20 ml of hot 10% solution of barium chloride. Continue boiling for 2 minutes, cover with a watch glass, and digest for several hours on a steam plate or water bath. Filter through a double thickness of Whatman No. 42 filter paper. Wash the precipitate until a separate 25 ml washing becomes only faintly opalescent upon addition of a few drops of

2% silver nitrate solution. Place the precipitate, together with the filter papers, in a tared platinum or porcelain crucible; dry, char, and ignite at 800°C to constant weight, and compute the weight of the barium sulfate precipitate.

Calculation

$$\begin{aligned} & \% \text{ Na}_2\text{SO}_4 \text{ by weight} \\ &= \frac{\text{g BaSO}_4 \times 0.6086 \times 100}{\text{Weight of Sample (as received)}} \end{aligned}$$

$$\begin{aligned} & \% \text{ Na}_2\text{SO}_4, \text{ A.B.*} \\ &= \frac{\% \text{ Na}_2\text{SO}_4 \text{ by weight} \times 100}{\% \text{ NaOH by weight}} \end{aligned}$$

Preparation of Special Indicator Solution

Methyl Orange Indicator Solution:

Dissolve 0.5 g of methyl orange in distilled water and dilute to one liter. This solution should be filtered if turbidity develops.

DETERMINATION OF LOW CONCENTRATIONS OF SODIUM SULFATE (Na_2SO_4)

Turbidimetric Method

Abstract

The method for measuring sodium sulfate in caustic soda involves the formation of finely divided barium sulfate in the acidified sample solution by treatment with an excess of solid barium chloride. The sample matrix must contain 14.6 g of sodium chloride per 100 ml of test solution. The turbidity due to barium sulfate is measured with a photometer.

Application

Mercury cell grade caustic soda.

Precision

The precision of the method is $\pm 0.002\%$ Na_2SO_4 by weight.

Reagents

Phenolphthalein indicator solution
Acid mixture
Concentrated hydrochloric acid (C.P.),
sp gr 1.19
Barium chloride crystals (turbidity
grade)

Procedure

Weigh a sample equivalent to approximately 10 g of anhydrous sodium hydroxide to 0.1 g into a 250 ml beaker. Add 1 drop of phenolphthalein indicator solution and neutralize with concentrated hydrochloric acid. This produces 14.6 grams of sodium chloride. Add 5 ml of acid mixture to the sample and dilute to 100 ml in a short-form Nessler tube. Prepare a blank in a separate Nessler tube containing 50 ml of 292.3 g/l sodium chloride (14.6 g) and 5 ml of acid mixture which is diluted to 100 ml volume, mixed thoroughly and stoppered.

Add 0.5 to 0.6 g of turbidity-grade barium chloride crystals, stopper the tube and mix by inverting and righting the tube through four cycles. Place in an upright position and allow to digest at room temperature for one hour without further mixing.

At the conclusion of the digestion period, mix the sample by inverting and righting the tube through three cycles and place a sufficient portion of the solution in the 5 cm comparison cell of the photometer and measure the blue light transmittance of the sample solution immediately as compared with distilled water adjusted to 100% blue light transmission. Measure the transmittance of the blank in like manner. Correct the sample dial for the blank dial in the following manner: $(100 - \text{blank dial}) + (\text{sample dial}) = \text{corrected dial}$. From the corrected

dial determine the grams of sodium sulfate from a current calibration curve.

Calculation

$$\begin{aligned} \% \text{Na}_2\text{SO}_4 \text{ by weight} &= \frac{\text{g Na}_2\text{SO}_4 \text{ from Chart} \times 100}{\text{Weight of Sample (as received)}} \\ \% \text{Na}_2\text{SO}_4, \text{ A.B.*} &= \frac{\% \text{Na}_2\text{SO}_4 \text{ by weight} \times 100}{\% \text{NaOH by weight}} \end{aligned}$$

Calibration of the Spectrophotometer

Measure 50 ml volumes of 292.3 g/l sodium chloride solution (14.6 g) into a series of 100 ml short-form Nessler tubes. Add 0.0, 0.5, 1.0, 1.5, 2.0, 3.0, 4.0, 5.0, 7.0, and 10.0 ml of the standard sodium sulfate solution respectively to the tubes. Mix thoroughly and add 5 ml of the acid mixture to each standard. Dilute each standard to 100 ml with distilled water and mix thoroughly. Add 0.5 to 0.6 g of barium chloride crystals to the standards at convenient intervals, to allow time for making turbidity measurements. One hour of digesting ± 5 minutes does not alter the analysis. Obtain the blue light transmittance as described in the general procedure, and compute the corrected dial for each standard. Construct a calibration curve plotting the grams of sodium sulfate versus corrected dial.

Special Reagents and Solutions

1. STANDARD SODIUM SULFATE SOLUTION:

Dissolve 0.5000 g of sodium sulfate (A.R.) in distilled water and dilute to 1000 ml and mix thoroughly. One ml of this solution is equivalent to 0.0005 g of sodium sulfate.

2. ACID MIXTURE:

Dissolve 0.2700 g of sodium sulfate (A.R.) in 1260 ml of distilled water.

Add 360 ml of 85% phosphoric acid (C.P.) and 180 ml of concentrated hydrochloric acid (sp gr 1.19) and mix thoroughly. Resulting solution equals 1800 ml. A 5 ml aliquot of this solution when added to the neutralized sample solution provides the optimum acidity for precipitating the sulfate.

3. SODIUM CHLORIDE SOLUTION:

Dissolve 292.3 g of sodium chloride (A.R.) in distilled water and dilute to 1000 ml. This is near a saturated solution so heat to expedite dissolution.

Note: The sodium chloride concentration influences the rate and quality of the barium sulfate suspension and must be carefully controlled.

DETERMINATION OF SODIUM CHLORATE (NaClO₃)

Arsenite-Bromate Method

Abstract

The method involves the reduction of the sodium chlorate in a caustic soda sample with an excess of standard sodium arsenite solution and the titration of the excess arsenite with standard potassium bromate solution. The arsenite consumed by the sample is a measure of the chlorate.

Application

Standard and low-iron grade caustic soda.

Precision

The precision of the method is $\pm 0.01\%$ NaClO₃ by weight.

Reagents

Standard solution of sodium arsenite (0.1N)

Standard solution of potassium bromate (0.1N)

Concentrated hydrochloric acid (C.P.),
sp gr 1.19

Methyl orange indicator solution

METHODS OF ANALYSIS

Procedure

Weigh a sample equivalent to 5.0 g of anhydrous sodium hydroxide to 0.1 g into a 250 ml beaker. Dilute the sample to approximately 75 ml with distilled water and mix thoroughly. Add a measured excess of 0.1N sodium arsenite solution. Add sufficient concentrated hydrochloric acid to result in a 2M excess with respect to the acid (a 2M excess is equivalent to 15 ml of 36 percent hydrochloric acid). Add several glass beads and heat to boiling.

Boil the solution for 3 minutes, add 7 drops 0.1 percent methyl orange indicator solution and immediately back-titrate the excess arsenite with standard potassium bromate solution to a colorless end point. Do not allow the solution to cool below 90° C during the titration. Compute the net volume of standard sodium arsenite solution consumed for the titration. The grams of chlorate are represented by the product of the respective net titration, normality and milliequivalent weight.

Calculation

$$\frac{\% \text{NaClO}_3 \text{ by weight} \times (\text{ml NaAsO}_2 \times N) - (\text{ml KBrO}_3 \times N) \times 0.01774 \times 100}{\text{Weight of Sample (as received)}}$$

% NaClO₃, A.B.*

$$= \frac{\% \text{NaClO}_3 \text{ by weight} \times 100}{\% \text{NaOH by weight}}$$

Special Reagents and Solutions

1. PREPARATION AND STANDARDIZATION OF SODIUM ARSENITE AND POTASSIUM BROMATE SOLUTION 0.1N:

Preparation: Dissolve 2.7836 g of potassium bromate (A.R.) in 500 ml of distilled water and dilute to one liter in a volumetric flask. Mix thoroughly.

Standardization: Measure 20 to 40 ml of standard 0.1N sodium arsenite solution from a burette into a 250 ml Erlenmeyer flask. Dilute to approximately 100 ml with distilled water and add 15 ml of concentrated hydrochloric acid (C.P.) sp gr 1.19. Heat the mixture to 95° C, add 6 drops of methyl orange indicator solution and titrate the mixture, while it is hot, with potassium bromate solution. When the indicator color has almost disappeared, reheat the solution, add one more drop of methyl orange indicator solution and continue the titration very slowly until the red color has disappeared.

$$\text{Normality of KBrO}_3 = \frac{\text{ml NaAsO}_2 \times N \text{ NaAsO}_2}{\text{ml KBrO}_3}$$

2. SODIUM ARSENITE SOLUTION 0.1N:

Preparation: Dissolve 6.496 g of sodium arsenite (A.R.) in 500 ml of distilled water. Transfer to a 1 liter volumetric flask and add 25 g of sodium bicarbonate (U.S.P.). Dilute the solution to 1 liter with distilled water and mix thoroughly.

Standardization: Dissolve 2 to 3 g of potassium iodide crystals (A.R.) in approximately 3 ml of distilled water contained in a suitable size weighing bottle and weigh to 0.1 mg. Place approximately 0.5 g of iodine crystals (A.R.) in the weighing bottle and reweigh to 0.1 mg. Record the increase in weight as the weight of iodine. Place the bottle and contents in a 400 ml beaker containing 200 ml of 1 percent potassium iodide solution. Titrate with the approximately 0.1N sodium arsenite solution until the mixture is straw yellow in color. Add 5 ml of starch indicator solution and continue titrating until the dark blue color of the iodine starch complex

disappears. Correct the volume of sodium arsenite used for the titration to 20° C.

$$\text{Normality of NaAsO}_2 = \frac{\text{g I}_2}{0.12692 \times \text{ml NaAsO}_2}$$

3. METHYL ORANGE INDICATOR SOLUTION:

Dissolve 0.5 g methyl orange in distilled water and dilute to 1 liter. This solution should be filtered if turbidity develops.

DETERMINATION OF LOW CONCENTRATIONS OF SODIUM CHLORATE (NaClO₃)

Distillation Method

Abstract

The method involves the determination of the net (total) oxidizing components in caustic soda by the decomposition of the chlorate with strong hydrochloric acid in the presence of excess potassium iodide. Free iodine equivalent to the chlorate content of the sample is liberated and subsequently distilled, and is dissolved in a dilute potassium iodide solution. The iodine is titrated with standard sodium thiosulfate solution. Corrections are applied for the iodine liberated by iron in the sample.

Application

Mercury cell and rayon grade caustic soda.

Precision

The precision of the method is $\pm 0.0001\%$ NaClO₃ by weight.

Reagents

Concentrated hydrochloric acid (C.P.), sp gr 1.19

* Anhydrous NaOH basis.

Potassium iodide, 5% solution, W/V
Starch indicator solution

Standard sodium thiosulfate solution
(0.01N)

Procedure

Weigh a sample equivalent to 12.5 g of anhydrous sodium hydroxide to 0.1 g into a 250 ml reaction flask containing 50 ml of distilled water.

Add 1 ml of 5% potassium iodide solution and several glass beads. Connect the reaction flask to the distillation apparatus. Charge the distillate receiver flask with 50 ml of 5% potassium iodide solution and position in the distillation apparatus in such a manner as to allow the delivery tube from the downward condenser to dip beneath the surface of the liquid. Carefully neutralize the sample in the reaction flask with concentrated hydrochloric acid by allowing the acid to drop from the separatory funnel supported in the neck of the reaction flask. Add 5 ml of concentrated acid in excess and close the stopcock. Heat the sample solution to boiling and distill for 10 to 15 minutes. Titrate the iodine distillate with standard sodium thiosulfate, using 5 ml of starch indicator. The end point is evidenced by the disappearance of the blue color of the iodine-starch complex. Correct the titration for a reagent blank similarly processed using distilled water in place of the sample.

Calculation

The grams of chlorate are represented by the product of the respective titration normality (corrected for blank) and milliequivalent weight. When desirable, the chlorate equivalents of other determined interfering elements (iron and manganese) may be subtracted from the total oxidizing value to obtain the net oxidizing value due to chlorate.

A = Total Oxidizing Components
as % NaClO₃ by weight =

$$\frac{(\text{ml Na}_2\text{S}_2\text{O}_3 \text{ for Sample} - \text{ml Na}_2\text{S}_2\text{O}_3 \text{ for Blank}) \times N \times 0.0177 \times 100}{\text{Weight of Sample (as received)}}$$

Corrections for Fe and Mn present:

$$B = \% \text{ NaClO}_3 \text{ equivalent to Fe} = \% \text{ Fe} \times 0.318$$

$$C = \% \text{ NaClO}_3 \text{ equivalent to Mn} = \% \text{ Mn} \times 0.65$$

$$\% \text{ NaClO}_3 \text{ by weight} = A - (B + C)$$

Special Reagents and Solutions

1. **CONCENTRATED HYDROCHLORIC ACID (C.P., low-iron),**
sp gr 1.19

2. **POTASSIUM IODIDE, 5% SOLUTION (W/V):**

Dissolve 25 g of potassium iodide crystals (A.R.) in distilled water and dilute to 500 ml. Prepare fresh daily.

3. **STARCH INDICATOR SOLUTION:** Prepare a thick starch paste by mixing 1.25 g of soluble starch with a few ml of distilled water. Heat 250 ml of distilled water to boiling and add the starch paste to the boiling water. Mix thoroughly and add 0.3 g of salicylic acid as a preservative to the hot starch solution. Cool and store in a suitable bottle. Prepare fresh weekly.

4. **SODIUM THIOSULFATE SOLUTION:**

Preparation of 0.1N Na₂S₂O₃: Dissolve 25 g \pm 0.1 g of sodium thiosulfate (A.R.) in 500 ml of freshly boiled and cooled distilled water and dilute to one liter with additional prepared distilled water. Add 5 ml of chloroform and allow the solution to age a few days before standardizing.

Standardization: Dissolve 2 to 3 g of potassium iodide crystals (A.R.) in approximately 3 ml of distilled water contained in a weighing bottle and weigh to 0.1 mg. Place approximately

0.5 g of iodine crystals (A.R.) in the weighing bottle and reweigh to 0.1 mg. Record the increase in weight as the weight of iodine.

Place the bottle and contents in a 400 ml beaker containing 200 ml of 1 percent potassium iodide solution. Titrate the iodine with the 0.1N sodium thiosulfate solution until the mixture is straw-yellow in color. Add 5 ml of starch indicator solution and continue titrating until the dark blue color of the iodine-starch complex disappears. Correct the volume of titrant to 20° C (see table on page 65).

$$\text{Normality of Na}_2\text{S}_2\text{O}_3 = \frac{\text{g I}_2}{0.12692 \times \text{ml Na}_2\text{S}_2\text{O}_3}$$

Preparation of 0.01N Na₂S₂O₃: Dilute standardized 0.1N Na₂S₂O₃ solution 1:10 with freshly boiled and cooled distilled water. The normality factor is calculated on the basis of the dilution ratio.

Notes

1. Boil out the equipment with distilled water after each determination.
2. When the iron and manganese corrections are found equal to the oxidizing components in the sample, it is assumed that the chlorate in the sample is zero.
3. When the iron and manganese corrections are greater than the determined total oxidizing properties of the sample, it may be assumed that the sample possesses reducing qualities. In such instances the reducing properties may be expressed in terms of chlorate equivalents (reducing).
4. The acidity, volume, and time of the distillation must be standardized because the iodine liberated is somewhat dependent on these variables.

METHODS OF ANALYSIS

DETERMINATION OF IRON (Fe)

o-Phenanthroline Colorimetric Method

Abstract

The method involves the determination of iron in caustic soda by the spectrophotometric measurement of the iron *ortho*-phenanthroline complex. The method entails acidification of the sample with hydrochloric acid, treatment with a solution of hydroxylamine hydrochloride to reduce the iron to Fe(II), adjustment of the pH value of the solution, and the addition of the complexing agent *ortho*-phenanthroline solution. The color of the solution is measured spectrophotometrically at a wavelength of 510 m μ . The procedure is standardized and performed in a sodium chloride matrix.

Application

All grades of caustic soda.

Precision

The precision of the method is $\pm 0.00005\%$ Fe by weight.

Reagents

Concentrated hydrochloric acid (C.P.), sp gr 1.19

Hydroxylamine hydrochloride solution, 10% W/V

Acetate buffer solution

o-Phenanthroline solution, 1% W/V

2,4-Dinitrophenol indicator solution, 0.1% W/V

Sodium chloride crystals (purified grade)

Procedure

Weigh a sample equivalent to 5.0 g of anhydrous sodium hydroxide to 0.1 g into a 125 ml beaker and dilute to 50 ml with distilled water. Add 0.5 ml

of dinitrophenol indicator solution and neutralize the sample with concentrated hydrochloric acid. Cool the solution to room temperature and then render slightly acidic by the addition of two drops of concentrated hydrochloric acid. Transfer the slightly acidic solution to a 100 ml volumetric flask and reserve.

Since the spectrophotometric measurements are made against a reagent blank containing 7.3 g of sodium chloride, its preparation should be initiated at this point in the analysis.

Weigh 7.3 g of purified sodium chloride (iron-free) into a 100 ml volumetric flask and dissolve in approximately 50 ml of distilled water. Add 0.5 ml of dinitrophenol indicator solution and neutralize by dropwise additions of concentrated hydrochloric acid or ammonium hydroxide, then render the solution slightly acidic by adding two drops of concentrated hydrochloric acid.

To both the sample and blank, add 1 ml of 10 percent hydroxylamine hydrochloride solution and mix thoroughly. Allow the solutions to digest 10 minutes to effect reduction of the iron to the ferrous state. After reaction add 10 ml of the acetate buffer solution and mix thoroughly. The pH of this solution should be between 4 and 5. Add 5 ml of *ortho*-phenanthroline solution, dilute to 100 ml with distilled water and mix the solutions thoroughly.

Allow the solutions to stand for 15 minutes, then transfer an appropriate volume of the prepared solutions to a 5 cm comparison cell of the spectrophotometer. Measure the transmittance of the sample at 510 m μ as compared with the blank.

Consult the calibration curve for the spectrophotometer to obtain the number of grams of iron in the sample.

Calculation

$$\begin{aligned} &\% \text{ Fe by weight} \\ &= \frac{\text{g Fe from Calibration Curve} \times 100}{\text{Weight of Sample (as received)}} \end{aligned}$$

$$\begin{aligned} &\% \text{ Fe, A.B.*} \\ &= \frac{\% \text{ Fe by weight} \times 100}{\% \text{ NaOH by weight}} \end{aligned}$$

Calibration of Spectrophotometer

Place 7.3 g of pure sodium chloride (iron-free) into a series of 100 ml volumetric flasks and dissolve the salt in approximately 30 ml of distilled water. Measure 0.0, 0.5, 1.0, 2.0, 4.0, 7.0, and 10.0 ml respectively of the standard iron solution into the flasks.

Add 0.5 ml of dinitrophenol indicator solution and neutralize by the dropwise addition of ammonium hydroxide, then render the solution slightly acidic by the addition of 2 drops of concentrated hydrochloric acid. Proceed with the preparation of the standards as described in the procedure above. Construct a calibration curve from the calibration data.

Special Reagents and Solutions

1. STANDARD IRON SOLUTION:

Dissolve 0.1000 g of iron (A.R.) in a mixture of 20 ml of hydrochloric acid and 50 ml of distilled water. Heat the mixture gently to expedite solution of the iron metal. When the solution is dissolved, dilute it to 1 liter with distilled water and mix. Dilute a 100-ml aliquot of this solution to 1000 ml and mix. One ml of the resulting solution contains 0.00001 g of iron.

2. ACETATE BUFFER SOLUTION:

Dissolve 272 grams of sodium acetate trihydrate in 500 ml of distilled water. Add 240 ml of glacial acetic acid, cool and dilute to one liter with distilled water.

3. o-PHENANTHROLINE SOLUTION, 1%(W/V):

Dissolve 5.0 g of 1,10-ortho-phenanthroline in methyl alcohol and dilute to 500 ml with alcohol. Store this solution in a glass-stoppered amber bottle. Prepare fresh solution each 3 to 4 weeks.

4. 2,4-DINITROPHENOL INDICATOR SOLUTION, 0.1%(W/V):

Dissolve 0.1 g of 2,4-dinitrophenol in distilled water and dilute to 100 ml.

5. HYDROXYLAMINE HYDROCHLORIDE SOLUTION, 10%(W/V):

Dissolve 50 g of hydroxylamine hydrochloride in distilled water and dilute to 500 ml.

Volumetric Temperature Correction Table

Temperature, °C	Water and 0.1N Solutions, ml/l ¹	1N HCl ²
15	+0.77	+0.97
16	+0.64	+0.79
17	+0.50	+0.61
18	+0.34	+0.41
19	+0.18	+0.21
20	0	0
21	-0.18	-0.22
22	-0.38	-0.44
23	-0.59	-0.67
24	-0.81	-0.91
25	-1.03	-1.17
26	-1.27	-1.43
27	-1.52	-1.70
28	-1.77	-1.98
29	-2.04	-2.26
30	-2.31	-2.55

¹"Handbook of Chemistry and Physics," 48th ed, The Chemical Rubber Company, Cleveland, Ohio, 1967-1968, p F2.

²"Chemical Annual," 7th ed, D. Van Nostrand Company, Inc., Princeton, New Jersey, 1934, p 71.

This table gives the correction to be added per liter to the observed volume of water, or standard 0.1N solution, to give the volume at the standard temperature 20°C. Conversely, by applying the corrections to the volume desired at 20°C, the volume that must be measured out at the designated temperature in order to give the desired volume at 20°C will be obtained. The volumes are measured in glass apparatus having a coefficient of cubical expansion of 0.000025 per degree C.

A formula for calculating volumetric temperature corrections appears in "ASTM Standards," Part 22, 1968, Designation E-200-67, page 457.

* Anhydrous NaOH basis.

USES OF CAUSTIC SODA

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

Caustic soda has a host of different uses. Its major markets are the chemical and pulp and paper industries, but considerable quantities of caustic soda are used to produce rayon, aluminum, soap, textiles and petroleum. Other high-volume uses include detergents and cleaners, boiler compounds, paint- and varnish-removers, water treatment, food processing and leather manufacturing.


Because of inherent processing advantages, caustic soda is replacing soda ash (sodium carbonate) as a source of sodium oxide in several uses. These include the manufacture of glass, paper pulp, phosphates and silicates, and water-treatment.




Chemical processing is the major user of caustic soda.



NaOH



Caustic soda is a major processing chemical for pulp and paper.



Caustic soda helps rayon set the style.



Soaps, detergents and cleaners all use caustic soda


METHODS OF MANUFACTURE

Caustic soda is a hazardous, reactive chemical. Before persons work with caustic soda, they should be instructed in safe handling practices and first aid, and should wear the recommended protective clothing and equipment (see chapter 3).

LIME-SODA PROCESS

The lime-soda process was the only commercial method of manufacturing caustic soda until 1890, when processes for simultaneous production of caustic soda and chlorine by the electrolysis of brine were introduced. Lime-soda process techniques improved over the centuries from the time soap was made in ancient days, but every process still depended on the reaction of slaked lime (calcium hydroxide) with soda ash (sodium carbonate) to produce caustic soda (sodium hydroxide) and calcium carbonate.


In chemical notation:



DIAPHRAGM CELL PROCESS

After 1890, the number of electrolytic chlor-alkali plants increased until, by 1940, most caustic soda was produced by the electrolysis of brine.

The diaphragm cell method is a one-step process. The over-all reaction is:



The earlier diaphragm cells consisted of a shell having a concrete bottom, a steel mid-section, and a concrete top. The electrodes consisted of a graphite anode and a steel wire mesh cathode. With the conversion to the dimensionally stable anodes (DSA) in the early 1970's and improved materials of construction, several changes in diaphragm cell design occurred. Instead of using concrete tops and bottoms, the modern diaphragm cells are constructed with steel bottoms and plastic tops. The DSA anodes are titanium with an electrolytic coating. The cathode is still steel but in selected cases an electrolytic coating is used. The conversion to DSA anodes provided a significant reduction in the cell power consumption. The diagram on the facing page shows a design of a modern monopolar diaphragm cell.

The anode and cathode are separated by a "diaphragm" made from a deposited layer of asbestos fiber that coats each cathode. The diaphragm serves to keep the caustic soda and hydrogen separated from the anolyte, but it also has an additional function by controlling the flow of electrolyte to the cathode. In this manner, the optimum efficiency in formation of caustic and chlorine can be maintained.

The electrolyte in the cell is a solution of sodium chloride. Natural salt, however, contains varying quantities of calcium, magnesium and other impurities. The brine is treated to remove these contaminants by precipitation. The brine is then filtered to remove the precipitates and any other undissolved solids that may be present. At this stage the brine has too low a concentration of sodium chloride for efficient cell operation. It is brought to the desired strength either by addition of purified salt or by evaporation of some of the water.

For convenience, cells are arranged in series electrically, each circuit consisting of several rows of cells. Two rows share a brine distribution line and collecting systems for chlorine and hydrogen. On the aisle side of each row is a pipe line for collecting caustic. Brine flow to each cell is individually controlled.


When direct current electricity flows between anodes and cathodes and through the brine, chlorine collects at the anode plates and hydrogen collects inside the cathode screen. Sodium combines with the hydroxyl ion of water to form caustic soda (sodium hydroxide) at the cathodes. The chlorine bubbles up through the brine and is carried away by the chlorine-collecting system. Similarly, hydrogen is collected from the cathode section. The caustic solution is drawn off from the cell's lower side.

The caustic solution as it comes from the cell is approximately 12 percent sodium hydroxide. The solution is evaporated to 50 percent or 73 percent sodium hydroxide. The latter can be further concentrated to the anhydrous state and sold in the form of PELS caustic soda beads.

NaOH



Circuit of diaphragm cells with dimensionally stable anodes.



METHODS OF MANUFACTURE

BIPOLAR DIAPHRAGM ELECTROLYZERS


The diaphragm cells just described are classed as monopolar; each cell in a series circuit is connected by bus bars. Bipolar electrolyzers consist of a number of bipolar diaphragm cells, usually eleven, in a series circuit of up to 20 electrolyzers. The bipolar design permits current to flow internally within an electrolyzer from one cell to another, instead of through external bus bars, which are needed only between electrolyzers.

The bipolar electrolyzer design is the result of a joint development effort begun by PPG and de Nora in 1969 after many years of working separately on bipolar cell design. These bipolar electrolyzers were commercialized in 1973.

The bipolar electrolyzers have dimensionally stable metal anodes made of titanium coated with mixed metal oxides. A constant small gap is maintained between anode and cathode, minimizing resistance loss through the electrode. Because the open

design of the dimensionally stable anodes lets the chlorine escape from behind, the resistive path in front of the anodes is also reduced.

The bipolar design also lowers the resistance through the electrolyte and in the fastenings and connections between cells of an electrolyzer. As a result, the cell voltage of bipolar electrolyzers is substantially less than that of monopolar diaphragm cells.




Bipolar diaphragm electrolyzer.

Each cell of a bipolar electrolyzer has its own brine reservoir made of fiberglass-reinforced polyester. The reservoir provides an emergency stand-by supply of brine in case brine flow to the cell should be temporarily stopped.

Bipolar electrolyzer cell rooms have portable cutout switches which permit single electrolyzers to be taken out of service without interrupting the operation of an entire circuit. The electrolyzer can be removed from the cell room to a cell renewal facility by a transporter system.

Major benefits of the bipolar electrolyzer include lower power consumption, high current efficiency, and reduced floor space requirements.




Bipolar element of electrolyzer.

METHODS OF MANUFACTURE


MERCURY CELL PROCESS

The mercury cell is really two cells. In the primary unit, chlorine and sodium are released by electrolysis of brine; the chlorine is drawn off, and the sodium dissolves in the mercury cathode, forming an amalgam. In the secondary unit, the sodium in this amalgam reacts with water, forming sodium hydroxide and releasing hydrogen. The reaction for this method is as shown.

The mercury cell process is in two steps. The overall reaction in the primary cell is:



The sodium produced at the cathode dissolves in the mercury to form an amalgam. The overall reaction in the secondary cell is:



There are several different types of mercury cells, some vertical, some horizontal. PPG Industries Chemicals

Group uses two types of horizontal cells, the German-designed Uhde cells and the Italian de Nora cells. The primary cell is a broad, shallow steel trough, quite long, although shorter than an average battery of diaphragm cells. The top is a tightly fitting flat steel plate, or rubber cover.

The sides of the cell and the underside of the cover, which come into contact with chlorine, are protected by a rubber lining.


The cathode is a slowly flowing stream of mercury which spreads across the floor of the cell. The mercury inlet end of the cell is slightly higher than the outlet end, so that the desired rate of flow is maintained by gravity. The metal anodes are dimensionally stable and mounted with the broad face parallel to the mercury bed. Vertical position of anodes is adjustable from outside the cell, permitting maintenance of optimum space between anodes and cathode (see diagram shown below).

The secondary cell, at one side of the primary, is of the same length but is much smaller in cross-section and is unlined. This cell is operated so that the mercury becomes the anode; graphite grids form the cathode. Anode and cathode are in contact. The cell functions, in effect, like an internally shorted battery.

Raw brine for the mercury cell process is purified and concentrated in much the same way as for the diaphragm cell process. The effluent of brine from the mercury cell is depleted by partial removal of chlorine and sodium. This brine is recovered, resaturated and recirculated.

The amalgam from the primary cell flows to the secondary cell. Pure water flows over this amalgam; its decomposition is aided by the electric current between the amalgam and the graphite grids; hydrogen is liberated and caustic soda solution is formed.

De Nora Mercury Cell



MEMBRANE CELL PROCESS

The membrane cell in many respects is similar to a diaphragm cell except that a high strength, high purity caustic is produced at the cell. Both monopolar and bipolar cells are available. The use of an ion exchange membrane in lieu of an asbestos diaphragm and nickel instead of steel construction for the cathode compartment constitute the major design differences. A schematic of a membrane cell is shown below.

Brine treatment for the membrane cell process is the same as for the diaphragm cell except that the purified brine is passed through an ion exchange resin. Also, since the brine does not pass through the membrane,


the depleted brine from the cell is normally recirculated in a closed loop system. This requires dechlorinating and resaturating the brine. The brine in selected situations is used on a "once through basis" by resaturating the depleted brine and feeding it to a diaphragm cell circuit.

In the electrolysis of brine, chlorine is produced at the anode. The sodium ion that is generated is selectively allowed to pass through the membrane. In the cathode compartment, hydrogen is produced at the cathode with the sodium ion reacting with the hydroxyl ion to the caustic soda. The caustic solution is recirculated and deionized water added to maintain the sodium hydroxide concentration at

normally between 32 to 35% depending on the membrane used. For certain membranes, a lower caustic concentration must be maintained.

Because of the higher caustic strength, the cathode compartment is generally constructed with nickel. Since the nickel cathode is not as good an electrode material as steel, an electrolytic cathode coating is generally used to minimize the cell power consumption.

The caustic solution from the cells can be used "as is" for most captive requirements or evaporated to 50 percent employing a relatively simplistic evaporator system. This high purity caustic can also be concentrated to 73 percent or to anhydrous caustic soda.



PPG CHEMICALS FOR INDUSTRY

Besides the chemicals listed here, a list of PPG visual training aids appears on page 75. A reference to the nine training aids is printed with the pertinent products.

ACID CHLORIDES

Pivaloyl, 2-Ethylhexanoyl, and Neodecanoyl Chlorides are commercially available. Other developmental and experimental acid chlorides can be ordered. 55-gal drum; tank trucks.

AIRCRAFT FUEL ANTI-ICING MICROBIOCIDAL, FUEL ADDITIVE

Military and commercial formulation. Tank cars and tank trucks.

Prist® Anti-icing Microbiocidal, Fuel Additive for business and general aviation. Cartons of 20-oz and 8-oz pressurized cans and 55-gal drums and 5-gal pails.

ANHYDROUS AMMONIA

Commercial and metallurgical-refrigeration grades. Tank trucks; 26- and 78-ton tank cars.

BIOCHEMICALS

Plant Growth Regulators and Herbicides

Bud Nip™

Systemic suck control agent for tobacco. Two 2-gal jugs/carton.

Chem Hoe®IPC

FL 4 (flowable): 5-gal pails; 15G (15% granular): 50-lb paper bags.

Furloc® Chloro IPC

EC (Emulsifiable Concentrate): Two 2½-gal jugs/carton. Granular: 20% active, 50-lb paper bags.

Genate Plus™

Selective corn herbicide. 55-gal drums. 2½-gal jug (2 per carton). Also in bulk.

Genep™ EPTC

Selective herbicide. 5-gal; two 2½-gal jugs/carton.

Sprout Nip® potato sprout inhibitor

Emulsifiable concentrate: 1-, 5- and 30-gal drums. Aerosol grade: 5-gal cans.

CALCIUM HYPOCHLORITE

Disinfectant, oxidizing agent, bactericide, algicide, and bleach. Free-flowing high-test calcium hypochlorite granules or tablets containing 65% available chlorine.

Pittclor® Granular

100-lb, 75-lb, 50-lb fiber drums. 25-lb PE pail. 6-lb PE jugs (6 per case).

Induclor™ Granular

400-lb, 100-lb fiber drums.

Repak™ Granular and Tablets

400-lb, 100-lb fiber drums.

Pittabs®

7 gram—¾" dia, ½" thick slow dissolving. High-test calcium hypochlorite tablet containing 65% available chlorine.

100-lb fiber drum. 35-lb PE pail. 7½-lb PE jugs (6 per case).

Zappif™ Super Chlorinator and Shock Treatment

Two decorative display boxes each containing 12 one-pound polyethylene pouches.

CARBONATES

Dimethyl and Diethyl Carbonates are commercially available. Some developmental and experimental carbonates can be ordered. 55-gal drums; tank trucks; tank cars.

CAUSTIC SODA

— Training Aids #1, 3, 4, 5

Liquid—Standard, Mercury Cell and Rayon Grades

50% and 73% concentrations: tank trucks; 8,000-, 10,000- and 16,000-gal insulated, lined tank cars. Also barges and ships (50% only).

Pels® Beads

500- and 100-lb drums; 50-lb bags, palletized and shrink-wrapped. Bulk (PD hopper cars and trucks).

CHLORINATED BENZENES

Dizene™

emulsifiable orthodichlorobenzene 55-gal drums (550 lb net); tank trucks; tank cars.

Monochlorobenzene

55-gal drums (500 lb net); 8,000-, 10,000- and 20,000-gal tank cars; tank trucks and barges.

Orthodichlorobenzene

Refined and technical grades: 55-gal drums (600 lb net); tank trucks; 8,000-, 10,000- and 20,000-gal tank cars.

Paradichlorobenzene

Solid in 5 mesh sizes; nuggets and coarse, medium, small and fine crystals. 300-lb fiber drums. Bulk liquid in tank trucks and 8,000- and 10,000-gal tank cars.

CHLORINATED C₂ HYDROCARBONS

Ethyl Chloride

Tank trucks, tank cars and barges.

Ethylene Dichloride

Tank trucks, tank cars, barges and ships.

CHLORINATED SOLVENTS

— Training Aids #6, 7, 8

Methylene Chloride

55-gal drums (600 lb net); also tank trucks.

Perchloroethylene (perchlor)

Dry cleaning and degreasing grades: 55-gal drums (70 lb net). Also tank trucks and barges; 4,000-, 8,000-, 10,000- and 20,000-gal tank cars.

Trichloroethylene (trichlor)

Degreasing, general solvent and high-purity grades: 55-gal drums (660 lb net). Also tank trucks and barges: 4,000-, 8,000-, 10,000- and 20,000-gal tank cars.

Tri-Ethane®

1, 1, 1-trichloroethane, stabilized

For metal degreasing, aerosols, adhesives, electronic applications and general solvent use: 55-gal drums (585 lb net); tank trucks; 4,000-, 8,000-, 10,000- and 20,000-gal tank cars.

CHLORINE

— Training Aid #2

Tank cars and barges

CHLOROFORMATES

Methyl, Ethyl, Isopropyl, Isobutyl, Allyl, sec-Butyl, 2-Ethylhexyl, Banzyl and Phenyl Chloroformates are commercially available. Many developmental and experimental chloroformates and bischloroformates can be ordered. 55-gal drums; tank trucks; tank cars.

ETHYLENE PRODUCTS

Monoethylene Glycol

Diethylene Glycol

Tank truck, tank cars, barges and ships.

Triethylene Glycol

Tank trucks and tank cars.

Ethylene Glycol Methyl Ethers (For jet fuel anti-icing uses only)

Tank trucks and tank cars.

Ethylene Oxide

Tank cars.

FLAME RETARDANT

ADDITIVES

(Available as powder in 50-lb drums, or in concentrate form)

†These products are available in developmental quantities.

†FSB-100

For synthetic fibers and polypropylene molding resins.

†FSB-113, FSB-136

For PBT and nylon resins.

†FSB-114

For ABS molding resin.

FSB-164

For crystal and expandable polystyrene resin.

FSB-183

For high-impact polystyrene, polyolefins and nylon resins, and for fiber applications.

FSB-190

For ABS molding resin.

FSB-300

For high-impact polystyrene.

FSB-310

For polyolefins and polystyrenes.

ADDITIVES (Available as liquids)

FSB-301

Water-based additive for cellulosic products such as FR paper.

FSB-302, FSB-303, FSB-304

Liquid bromine - phosphorus additive for unsaturated polyesters, phenolics, polyurethanes & PVC.

CONCENTRATES

FSPE-105

Designed for HDPE applications.

FSPE-115

Designed for LDPE applications including extrusion onto wire.

FSPE-125

Designed for PE injection molding applications.

FSPP-205

Designed for V-2 polypropylene applications.

FSPP-215

Designed for V-0 polypropylene applications.

Antimony Oxide Concentrates

Concentrates of antimony trioxide are available in PE, EVA, PP, CLPE, TPE, ABS, PS, SAN, PBT and Nylon.

COMPOUNDS

(Ready-to-use flame retardant polyolefin compounds that meet UL-94 specifications)

FSPE-101

Polyethylene compound for wire and cable application, 50-lb paper bags.

FSPP-201

V-0 polypropylene homopolymer compound for molding applications. All colors. 1500-lb boxes.

FSPP-211

V-0 polypropylene copolymer compound for molding use. All colors. 1500-lb boxes.

FSPP-231, FR-4145, FR-4348

V-2 polypropylene compounds specially designed for molded electrical parts. All colors. 1500-lb boxes.

FSPP-241

Low specific gravity V-0 polypropylene compound containing no halogen or antimony oxide.

FLATTING AGENTS

Ultrafine Amorphous Silica Powders

Highly efficient agents for reducing gloss of paints, varnishes and lacquers. Textile delustrant. Thickener. Carrier. Light bulb coating.

Lo-Vel® 27 and 66 for furniture lacquer and vinyl fabric topcoat lacquer and wherever Hegman 6 is required.

Lo-Vel 27 in 20-lb bags.

Lo-Vel 66 in 10-lb bags.

Lo-Vel® 275 for coil coatings and clear finishes. 25-lb bags.

Lo-Vel® 28 for coil coatings and varnishes. 25 lb-bags.

Lo-Vel® 29 for coil coatings used for house siding. 25-lb bags.

Lo-Vel® 39A for textured finishes. Sanding aid for auto primer paint: 25-lb bags.

All grades of **Lo-Vel** silica bags are palletized and stretch-wrapped.

MONOMERS

CR-39® Allyl Diglycol Carbonate Monomer

For manufacturing optical plastic products. 5-gal drums (45 lb net). 55-gal drums (500 lb net).

Vinyl Chloride Monomer

Bulk (tank cars, barges and ships).

Vinylidene Chloride Monomer

50- and 90-ton tank cars; tank trucks.

MURIATIC ACID

Hydrochloric acid—20° Baumé

Tank trucks; 8,000-, 10,000- and 20,000-gal rubber-lined tank cars.

ORGANIC PEROXIDES

EHP (ethylhexyl percarbonate)

Polymerization initiator for ethylene and vinyl chloride; shipped in 1-gal bottles; in trucks with special permits. Available as dilute solutions.

IPP (isopropyl percarbonate)

Polymerization initiator for CR-39, ethylene, vinyl chloride and methacrylate: shipped frozen in 10-lb trays; in trucks with special permits. Available as commercially pure or as dilute solutions.

NPP (normal propyl percarbonate)

Polymerization initiator for CR-39, ethylene, vinyl chloride and methacrylate: shipped in 1-gal bottles; in trucks with special permits. Available as commercially pure or as dilute solutions.

SBP (secondary butyl percarbonate)

Polymerization initiator for CR-39, ethylene, vinyl chloride and methacrylate: shipped in 1-gal gottles; in trucks with special permits. Available as commercially pure or as dilute solutions.

40% SBP and 40% EHP frozen emulsion

Polymerization initiator primary for use in aqueous systems such as the suspension polymerization of vinyl chloride. Shipped frozen in cartons holding 30 lbs. Special shipping permits not required.

PHOSGENE

1-ton net tanks on trucks and multi-unit tank cars.

POLYCARBONATE DIOLS

Duracarb™ 120 series diols—polyols for polyurethane elastomer applications. 55-gal drum.

Duracarb™ 140 series diols—polyols for hard plastic polyurethane applications. 55-gal drum.

POTASH

Potassium Chloride

Trucks and railcars. 55-lb bags.

PULP AND PAPER PERFORMANCE CHEMICALS

Process aids, paper additives and pulping and bleaching aids.

SILICA PRODUCTS

Hi-Sil® 132, 233 and 250 Powders

Hi-Sil® 243 LD Low Dust

Hi-Sil® 210 Pellets

Extremely fine particle hydrated amorphous silicas for rubber reinforcing, agricultural chemicals, flow conditioning, plastics, paints: **Hi-Sil 132, 233 and 250** in 44-lb (20-kg) paper bags palletized and stretch-wrapped; **Hi-Sil 210** in 44-lb (30-kg) polyethylene bags; **Hi-Sil 243** in 50-lb paper bags.

Hi-Sil® 532 EP

Fine-particle hydrated silica for rubber reinforcing, agricultural chemicals, flow con-

ditioning, plastics, paints: 44-lb (20-kg) paper bags palletized and stretch-wrapped.

Hi-Sil® T-600

Thixotropic thickener: 20-lb bags.

Silene® 732 D

Medium-reinforcing hydrated silica pigment for improved rubber and plastics processing: 44-lb (20-kg) paper bags palletized and stretch-wrapped.

Flo-Gard® AG, CC and FF Powders

Highly absorbent, ultrafine, hydrated, amorphous silicas.

Flo-Gard® AG 110, 130, 150

Can serve in pesticides as carriers for liquids, grinding aids for solid toxicants, suspension aids and anticaking agents. Can serve in animal feeds as liquid carriers and anticaking agents.

Flo-Gard® CC 120, 140, 160

Can serve as chemical carriers and flow control agents in the process industries.

Flo-Gard® FF 310, 320, 330, 350, 370, 390

Can serve as flow control and anticaking agents in the process industries.

All **Flo-Gard®** grades are shipped in paper bags, palletized and stretch-wrapped. Grades 110, 120, 310, 320, 330: 44-lb bags. Grades 130, 140, 350: 25-lb bags. Grades 150, 160, 370, 390: 10-lb bags.

SODIUM CHLORATE

Technical grade in bulk carloads and truckloads available at Beauharnois, Quebec, Canada, only.

SULFIDE COMPOUNDS

Carbon Disulfide

55-gal drums (550 lb net); 4,000-, 8,000-, 10,000-, 18,000- and 20,000-gal tank cars.

Hydrogen Sulfide

75-lb net cylinders: 1,085-lb net tanks.

Sodium Hydrosulfide

Flake: 400-lb drums; liquid, 45% and 60% (basis 100%): tank trucks and 4,000-, 8,000-, 10,000- and 20,000-gal tank cars.

Sodium Sulfide

— Training Aid #9

Flake: 400-lb drums.

Sodium Tetrasulfide

— Training Aid #9

Liquid, 34%: 55-gal drums (550 lb net).

PPG Training Aides

1. "Be Careful with Caustic." 16 mm Sound Film (20 minutes).
2. "Safety First with Chlorine." 16 mm Sound Film; also available in video (20 minutes).
3. "The Closed System Delivery." 35 mm Slide/Sound presentation. Describes bulk unloading of Pels Beads (20 minutes).
4. "Super Bead." 35 mm Slide/Sound presentation. Describes properties of Pels* Beads, compares Pels Beads with flake (20 minutes).
5. "The Safe Handling of Pels Beads." 35 mm Slide/Sound presentation (25 minutes).
6. "The Case of the Sneaky Vapors" (The Common Sense of Solvents Safety). 35

mm Slide/Sound presentation. Describes safe receiving and handling practices, and use of metalworking solvents (31 minutes).

7. "Save on Solvents." 35 mm Slide/Sound presentation. Describes solvent conservation practices. Lists ways to prevent waste (20 minutes).

8. "The ABC's of Vapor Degreasing Conversion." 35 mm Slide/Sound presentation. Describes in step-by-step fashion the procedure necessary to convert from trichloroethylene to Tri-Ethane* or perchlorethylene (15 minutes).

9. "SSDS" (Sodium Sulfide Delivery System: Liquid Sodium Sulfide/Sodium Sulfhydrate for Bulk Systems). 35 mm Slide/Sound presentation (15 minutes).

SALES OFFICES IN THE U.S.

CHICAGO (SCHAUMBURG) ILLINOIS 60195

1100 Woodfield Road
2 Woodfield Lake
(312) 885-3610

CLEVELAND, OHIO 44130

16600 Sprague Road
Suite 340
(216) 826-3600

HOUSTON, TEXAS 77090

530 Wells Fargo Drive
Suite 212
(713) 440-3770

NEW YORK (FLORHAM PARK,

NEW JERSEY) 07932
River Edge Office Center
Building A - 25 Veeland Road
(201) 966-1477

PHILADELPHIA (HADDONFIELD,

NEW JERSEY) 08033
The Centennial Building
76 Euclid Avenue
Philadelphia (215) 564-3390
New Jersey (609) 428-7800

SAN FRANCISCO (BURLINGAME)
CALIFORNIA 94010

851 Burlway
Suite 518
(415) 697-0100



PPG INDUSTRIES, Inc.
One PPG Place
Pittsburgh, 15272

The statements and methods presented about the products mentioned herein are based upon the best available data and practices known to PPG Industries at the present time, but are not representations or warranties of performance, results or comprehensiveness of such data, nor do they imply any recommendations to infringe any patent or an offer of license under any patent.

If not properly used, the products mentioned herein can be hazardous. All purchasers of these products should communicate all the health and safety information contained herein to their customers or employees, as the case may be. PPG Industries recommends that, before anyone uses or handles the products mentioned herein, he should read and understand the precautionary and other information on the product label, as well as in the Material Safety Data Sheet and Product Bulletin.

Although the products mentioned herein are intended for industrial and manufacturing uses, they are potentially hazardous materials and must be kept out of the reach of children.